

REVISIONS

The information compiled in the Pilot's Operating Manual will be kept current by revisions distributed to the airplane owners.

Revision material will consist of information necessary to update the text of the present manual and/or to add information to cover added airplane equipment.

I. Revisions

Revisions will be distributed whenever necessary as complete page replacements or additions and shall be inserted into the manual in accordance with the instructions given below:

1. Revision pages will replace only pages with the same page number.
2. Insert all additional pages in proper numerical order within each section.
3. Page numbers followed by a small letter shall be inserted in direct sequence with the same common numbered page.

II. Identification of Revised Material

Revised text and illustrations shall be indicated by a black vertical line along the left hand margin of the page, opposite revised, added or deleted material. A line opposite the page number or section title and printing date, will indicate that the text or illustration was unchanged but material was relocated to a different page or that an entire page was added.

Black lines will indicate only current revisions with changes and additions to or deletions of existing text and illustrations. Changes in capitalization, spelling, punctuation or the physical location of material on a page will not be identified by symbols.

PILOT'S OPERATING MANUAL LOG OF REVISIONS

Current Revisions to the PA-28-151 Cherokee Warrior Pilot's Operating Manual, 761 563, issued July 17, 1973.

Revision	Revised Pages	Description	Date
Rev. 1 - 761 563 (PR730801)	AFM	Added Rev. 1 to Report VB-573	Aug. 1, 1973
Rev. 2 - 761 563 (PR730830)	AFM W/B	Added Rev. 2 to Report VB-573 Added Rev. 1 to Report VB-535	Aug. 30, 1973
Rev. 3 - 761 563 (PR740125)	1-1 2-10 4-6 W/B 7-i 7-5 7-9 7-10 7-11 8-1 9-2	Revised Weights Revised overvoltage relay reset time. Revised Alternator Failure Item 3. Added Rev. 2 to Report VB-535 Added Airspeed Data; revised ELT. Revised Takeoff - Short Field, Soft Field Added Airspeed Data; relocated ELT to Page 7-10. Added ELT from Page 7-9; moved info to Page 7-11. Added Page. Revised Item 6. Revised Takeoff Distance Vs Density Attitude Chart.	Jan. 25, 1974

TABLE OF CONTENTS

GENERAL SPECIFICATIONS

DESCRIPTION - AIRPLANE AND SYSTEMS

AIRPLANE FLIGHT MANUAL F.A.A. APPROVED

EMERGENCY PROCEDURES F.A.A. APPROVED

EMERGENCY PROCEDURES

WEIGHT AND BALANCE

LOADING INSTRUCTIONS

OPERATING INSTRUCTIONS

OPERATING TIPS

PERFORMANCE CHARTS

HANDLING AND SERVICE

GENERAL SPECIFICATIONS

GENERAL SPECIFICATIONS

Performance	1-1
Weights	1-1
Power Plant	1-2
Fuel and Oil	1-2
Baggage	1-2
Dimensions	1-2
Landing Gear	1-2
3-View	1-3

GENERAL SPECIFICATIONS

PERFORMANCE

Published figures are for standard airplanes flown at gross weight under standard conditions at sea level, unless otherwise stated. Performance for a specific airplane may vary from published figures depending upon the equipment installed, the condition of engine, airplane and equipment, atmospheric conditions and piloting technique. Each performance figure below is subject to the same conditions as on the corresponding performance chart from which it is taken in the Performance Charts Section.

Takeoff Ground Run (minimum) (ft)	1065
Takeoff Distance Over 50-ft Obstacle (25° flaps) (ft)	1760
Best Rate of Climb Speed (mph)	87-77 KTS
Rate of Climb (ft per min)	649
Service Ceiling (ft)	12,700
Absolute Ceiling (ft)	14,960
Top Speed (mph)	135*
Optimum Cruising Speed (75% power, optimum altitude, leaned to best power) (mph)	133*
Cruising Range (75% power, optimum altitude, leaned to best economy, no reserves) (mi)	720*
Optimum Cruising Range (55% power, optimum altitude, leaned to best economy, no reserves) (mi)	785*
Stalling Speed (flaps down) (mph)	58 - 50 KTS
Stalling Speed (flaps up) (mph)	64.5 - 56 KTS
Landing Roll (flaps down) (ft)	595
Landing Roll Over 50-ft Barrier (flaps down) (ft)	1115

WEIGHTS

Gross Weight (lbs)	2325 -
Empty Weight (Standard) (lbs)	1301**
USEFUL LOAD (Standard) (lbs)	1024**

*With Optional Wheel Fairings installed.

**Weight varies with each aircraft.

CHEROKEE WARRIOR

POWER PLANT

Engine (Lycoming)	O-320-E3D
Rated Horsepower	150
Rated Speed (rpm)	2700
Bore (inches)	5.125
Stroke (inches)	3.875
Displacement (cubic inches)	319.8
Compression Ratio	7:1
Dry Weight (pounds)	276
Propeller	
McCauley	1C160/EGM7653
Sensenich	74DM6-0-58

FUEL AND OIL

Fuel Capacity (U.S. gal) (standard)	50
Fuel Capacity (U.S. gal) Usable	48
Oil Capacity (qts)	8
Fuel, Aviation Grade (min octane)	80/87

BAGGAGE


Maximum Baggage (lbs)	200
Baggage Space (cubic ft)	24
Baggage Door Size (in.)	20 x 22

DIMENSIONS

Wing Span (ft)	35
Wing Area (sq ft)	170.0
Length (ft)	13.7
Height (ft)	23.8
Wing Loading (lbs per sq ft)	7.8
Power Loading (lbs per hp)	15.6
Propeller Diameter (in.)	
McCauley	76
Sensenich	74
Turning Radius	13.0

LANDING GEAR

Wheel Base (ft)	6.5
Wheel Tread (ft)	10.0
Tire Pressure (psi)	
Nose	30
Main	24
Tire Size	
Nose (4 ply rating)	5.00 x 5
Main (4 ply rating)	6.00 x 6



**DESCRIPTION
AIRPLANE AND SYSTEMS**

DESCRIPTION AIRPLANE AND SYSTEMS

The Airplane	2-1
Airframe	2-1
Engine and Propeller	2-2
Landing Gear	2-4
Flight Controls	2-6
Fuel System	2-7
Electrical System	2-9
Vacuum System	2-13
Instrument Panel	2-13
Pitot-Static System	2-15
Heating and Ventilating	2-15
Cabin Features	2-18
Baggage Area	2-18
Stall Warning	2-18
Finish	2-18
Winterization Plate	2-19
Emergency Locator Transmitter	2-19
Piper External Power	2-19

DESCRIPTION

AIRPLANE AND SYSTEMS

THE AIRPLANE

The Cherokee Warrior is a single-engine, fixed gear monoplane of all metal construction with low semi-tapered wings.

The fuselage provides a spacious, four-place interior with optional features to ensure individual comfort during short or extended cross-country flight.

The Cherokee Warrior can serve as a rental or cross-country airplane and also as a training and utility airplane. Performance and loading characteristics combine with economical operation to make the Warrior a versatile airplane in the business or personal aviation fields.

AIRFRAME

The **primary structure**, with the exception of the steel tube engine mount, steel landing gear struts and isolated areas, is of **aluminum alloy construction** designed to ultimate load factors well in excess of normal requirements. Tough fiberglass and thermoplastic are used extensively in the extremities - the wing tips, the engine cowling, etc. - and in nonstructural components throughout the airplane.

The **fuselage** is a conventional semi-monocoque structure. On the right side of the airplane is a large cabin door for ease of entrance and exit and a large baggage door to provide effortless loading into the 24 cubic foot compartment. Maintenance has been reduced to a minimum with advanced fuselage design.

The **wing** is a conventional semi-tapered design incorporating a laminar flow, NACA 65₂ 415, airfoil section. The cantilever wings are attached to each side of the fuselage by insertion of the butt ends of the main spars into a spar box carry-through which is an integral part of the fuselage structure. The spar box carry-through structure, located under the rear seat, provides in effect a continuous main spar with splices at each side of the fuselage. There are also fore and aft attachments at the rear and at an auxiliary front spar. This type of wing structure provides unobstructed cabin space for the rear passengers and allows for a lighter wing structure to improve the useful load of the airplane.

Both **ailerons** and **flaps** are of modern, all metal construction for smooth control of the aircraft. The ailerons are tapered to accommodate the semi-tapered wings. In the fully retracted position, the **right flap** locks to provide a step for cabin entry. The flaps have three extended positions: 10, 25, and 40 degrees.

A horizontal stabilator, vertical fin, and a rudder make up the **empennage**. They utilize a lightweight metal construction with fiberglass tips. Directional and pitch trim are provided by the rudder and stabilator trim tabs respectively.

CHEROKEE WARRIOR

ENGINE AND PROPELLER

The PA-28-151 is powered by a Lycoming O-320-E3D four cylinder, direct drive, horizontally opposed engine rated at 150 HP at 2700 RPM. It is equipped with a starter, a 60 amp 14 volt alternator, a shielded ignition, dual magnetos, vacuum pump drive, a fuel pump, and a wetted polyurethane foam induction air filter. A recommended **overhaul period** of 2000 hours is based on Lycoming service experience. Operation beyond the recommended time is the decision of the operator. Since Lycoming from time to time revises the recommended overhaul period, the owner should check with his dealer for the latest overhaul period on his engine as well as any additional Lycoming Service Information.

The **engine compartment** is easily accessible for inspection through top-hinged side panels on either side of the engine cowlings. The engine cowlings are cantilever structures attached at the fire wall. The engine mounts are constructed of steel tubing, and dynafocal mounts are provided to reduce vibration.


The **exhaust system** is constructed of stainless steel and incorporates a single muffler with heater shrouds to supply heated air for the cabin, the defroster system and the carburetor deicing system.

An **oil cooler** is located on the left rear of the engine mounted to the engine baffling. Engine cooling air, which is picked up in the nose section of the engine cowling and carried through the baffling, is utilized on the left side for the oil cooler. A **winterization plate** is provided to restrict air during winter operation. (See Winterization in Handling and Servicing.)

Engine air enters on either side of the propeller through openings in the nose cowling and is carried through the engine baffling around the engine and oil cooler. Air for the muffler shroud is also picked up from the nose cowling and carried through a large duct to the shroud. Carburetor **induction air** enters a chin scoop on the lower right cowling and is passed through a wetted polyurethane filter to the carburetor air box. Heated air enters the carburetor air box through a hose connected to the heater shroud.

A McCauley 1C160/EGM7653 or a Sensenich 74DM6-0-58 **fixed pitch** propeller is installed as standard equipment. The McCauley propeller has a diameter of 76 inches with a pitch of 53 inches and the Sensenich has a 74 inch diameter with a 58 inch pitch. The pitch of both propellers is determined at 75% of the diameter. Both propeller units are of an aluminum alloy construction.

The pilot should read and follow the procedures recommended in the **Lycoming Operator's Manual** for this engine in order to obtain maximum engine efficiency and time between engine overhauls.



Throttle Quadrant and Console


LANDING GEAR

The **fixed gear** PA-28-151 is equipped with is a Cleveland 5.00 x 5 wheel on the nose gear and a Cleveland 6.00 x 6 wheel on each main gear. Cleveland single disc hydraulic brake assemblies are provided on the main gear. The nose gear has a 5.00 x 5 four ply tire, while the main wheel assemblies have 6.00 x 6 four ply tires. At gross weight, the main gear tires require a pressure of 24 psi, and the nose gear tire requires a pressure of 30 psi.


The **nose gear** is steerable through a 30 degree arc each side of center by the use of the rudder pedals and toe brakes. A spring device is incorporated for rudder centering and to provide rudder trim. A **bungee** assembly on the nose gear steering mechanism reduces ground steering effort and dampens shocks and bumps during taxiing. The steering mechanism also incorporates a **shimmy dampener**.

The three struts are of the **air-oil** type with the normal static load extension being 3.25 inches for the nose gear and 4.50 inches for the main gear.

The **brakes** are actuated by toe brake pedals which are attached to the rudder pedals or by a hand lever and master cylinder located below and behind the center of the instrument sub panel. Hydraulic cylinders are located above each pedal and adjacent to the hand brake lever. The brake fluid **reservoir** is installed on the top left front face of the fire wall. The **parking brake** is incorporated in the master cylinder and is actuated by pulling back on the brake lever and depressing the knob attached to the left side of the handle. To release the parking brake, pull back on the brake lever to disengage the catch mechanism and allow the handle to swing forward.



Main Wheel Assembly



Console

FLIGHT CONTROLS

Dual flight controls are provided on the Warrior as standard equipment. The flight controls actuate the control surfaces through a cable system.

The horizontal surface (stabilator) is of the flying tail design with a trim tab mounted on the trailing edge. This tab serves the dual function of providing trim control and pitch control forces. The trim tab is actuated by a trim control wheel located on the control console between the front seats. Forward rotation of the wheel gives nose down trim and aft rotation gives nose up trim. The stabilator provides extra stability and controllability with less area, drag and weight than conventional tail surfaces.

The rudder is conventional in design and incorporates a rudder trim. The trim mechanism is a spring loaded recentering device. The trim control is located on the right side of the pedestal below the throttle quadrant. Turning the trim control clockwise gives nose right trim and counterclockwise rotation gives nose left trim.

Ailerons are provided with a differential deflection. This feature reduces adverse yaw in turning maneuvers, thus reducing the amount of coordination required. An aileron centering spring incorporated in the aileron control system centers the aileron by returning the control wheel to neutral.

Manually controlled **flaps** are provided on the PA-28-151. The flaps are balanced for light operating forces and spring loaded to return to the retracted (up) position. A control handle, which is located between the two front seats on the control console, extends the flaps by the use of a control cable. To extend the flaps, the handle is pulled up to the desired flap setting of 10, 25 or 40 degrees. To retract, depress the button on the end of the handle and lower the control. When extending or retracting flaps, there is a pitch change in the airplane. This pitch change can be corrected either by stabilator trim or increased control wheel force. When the flaps are in the retracted (up) position the right flap, provided with an over-center lock mechanism, acts as a step.

NOTE

The right flap will support a load only in the fully retracted (up) position. When the flap is to be used as a step, make sure the flaps are in the retracted (up) position.

FUEL SYSTEM

Fuel is stored in two twenty-five gallon (24 gallons usable) fuel tanks, giving the airplane a total capacity of fifty U.S. gallons (48 gallons usable). The tanks are secured to the leading edge of each wing with screws and nut plates. This allows easy removal for service or inspection.

Each fuel tank has two outlets, one forward and one aft, to ensure an even fuel flow. Fuel is pumped from the tanks through the forward and aft tank outlets to fuel manifolds in the inboard section of either wing. Each manifold is a small collector with an inlet hose from each of the tank outlets, and an outlet hose to the fuel selector valve.

The fuel tank selector control is located on the left side panel forward of the pilot's seat. The button on the selector cover must be depressed and held while the handle is moved to the OFF position. The button releases automatically when the handle is moved back to the ON position.


An auxiliary electric fuel pump is provided in case of the failure of the engine driven pump. The electric pump should be ON for all takeoffs and landings and when switching tanks. The fuel pump switch is located in the switch panel above the throttle quadrant.

The fuel drains should be opened daily prior to first flight to check for water or sediment. Each tank has an individual drain at the bottom, inboard rear corner, and each fuel manifold is equipped with a drain. The outlets are located on the underside of the wings.


A gascolator, located on the lower left front of the fire wall, has a drain which is accessible from outside the nose section. The gascolator should also be drained before the first flight of the day. (See the Handling and Servicing Section for the complete fuel draining procedure.)

Fuel quantity and fuel pressure gauges are mounted in a gauge cluster located on the left side of the instrument panel to the right of the control wheel.

An optional engine priming system is available to facilitate starting. The primer pump is located to the immediate left of the throttle quadrant.



Fuel System Schematic



Fuel Selector

ELECTRICAL SYSTEM

The Cherokee Warrior is equipped with a simple but highly efficient electrical system that can be easily operated.

The electrical system includes a 14 volt 60 ampere alternator, voltage regulator, overvoltage relay, battery contactor and a standard 12 volt 25 ampere hour or an optional 12 volt 35 ampere hour battery. The battery is mounted in a thermoplastic box located immediately aft of the main spar on the right side of the fuselage below the rear passengers seat. The voltage regulator and overvoltage relay are located on the forward left side of the fuselage behind the instrument panel.

Electrical switches are located on the right center instrument panel, and the circuit breakers are located on the lower right instrument panel. A rheostat switch on the left side of the switch panel controls the optional navigation lights and the radio lights. A similar switch on the right side of the switch panel controls and dims the optional panel lights. The master switch, anti-collision light, landing light and fuel pump are also located on the switch panel and are controlled by rocker type switches. A hinged door protects and gives easy access to the circuit breaker panel. Each circuit breaker on the panel is of the push to reset type and is clearly marked as to its function and amperage. Circuit provisions have been included to handle a full complement of communication and navigational equipment.

CHEROKEE WARRIOR

Standard electrical accessories include a starter, an electric fuel pump, an audible stall warning indicator, fuel gauges and an ammeter.

The system also provides for such **optional electrical accessories** as additional lights and gauges, a heated pitot head, and communication and navigational equipment.

The master switch is a split rocker switch. One side of the switch is the battery side ("BAT") and the other is the alternator side ("ALT"). Henceforth, the words "**master switch**" used in this manual will mean both "BAT" and "ALT" switches and they are to be depressed simultaneously to OFF or ON as directed.


Primary electrical power is provided by the 14 volt 60 amp alternator. The alternator system offers many advantages over the generator system both in operation and maintenance. The main advantage is full electrical power output at lower engine RPM. This provides improved radio and electrical equipment operation and increased battery life by reducing battery load. This will make cold weather starting easier.

Secondary electrical power is provided by the standard or optional battery.


Unlike previous generator systems, the **ammeter** as installed does not show battery discharge; rather, it indicates the electrical load on the alternator in amperes. With all the electrical equipment off and the master switch on, the ammeter will indicate the charging rate of the battery. As each electrical unit is switched on, the ammeter will indicate the total ampere draw of all the units including the battery. For example, the maximum continuous load for night flight with radios on is about 30 amperes. This 30 ampere value plus approximately 2 amperes for a fully charged battery will appear continuously under these flight conditions. The amount of current shown on the ammeter will tell immediately if the alternator system is operating normally, as the amount of current shown should equal the total amperage drawn by the electrical equipment which is operating.

If no output is indicated on the ammeter during flight, reduce the electrical load by turning off all unnecessary electrical equipment. Check both the 5 ampere field breaker and the 60 ampere output breaker and reset if open. If neither circuit breaker is open, turn the "ALT" switch off for 1 second to reset the overvoltage relay. If the ammeter continues to indicate no output, maintain minimum electrical load and terminate the flight as soon as practical.

Maintenance on the alternator should prove to be a minor factor. Should service be required, contact the local Piper Dealer.



Alternator and Starter Schematic



Circuit Breaker Panel

VACUUM SYSTEM*

The vacuum system is designed to operate the air driven gyro instruments. This includes the directional and attitude gyros when installed. The system consists of an engine driven vacuum pump, a vacuum regulator, a filter and the necessary plumbing.

The vacuum pump is a dry type pump which eliminates the need for an air/oil separator and its plumbing. A shear drive protects the pump from damage. If the drive shears, the gyros will become inoperative.

A vacuum gauge, mounted on the far right instrument panel provides a pilot check for the system during operation. A decrease in pressure in a system that remained constant over an extended period may indicate a dirty filter, dirty screens, possibly a sticky vacuum regulator or leak in the system. Zero pressure would indicate a sheared pump drive, defective pump, possibly a defective gauge or collapsed line. In the event of any gauge variation from the norm, the pilot should have a mechanic check the system to prevent possible damage to the system components or eventual failure of the system.

A vacuum regulator is provided in the system to protect the gyros. The valve is set so the normal vacuum reads $5.0 \pm .1$ inches of mercury, a setting which provides sufficient vacuum to operate all the gyros at their rated RPM. Higher settings will damage the gyros and with a low setting the gyros will be unreliable. The regulator is located behind the instrument panel.

INSTRUMENT PANEL


The instrument panel is designed to be functional and professional, accommodating complete instruments and avionics equipment for VFR and IFR flights. A wide range of optional instruments and avionics permit an equipment selection to suit individual needs.

A natural separation of the flight group and power group is provided by placing the flight group in the upper instrument panel and the power group in the center and lower instrument panels. The radios and the circuit breakers are located on the upper and lower right panel respectively, and have circuits provided for a complete line of optional radio equipment. An engine cluster is located to the right of the pilot control wheel and includes a fuel pressure gauge, a right and left main fuel quantity gauge, an oil temperature gauge and an oil pressure gauge.

Standard instruments on the Warrior panel include a compass, an airspeed indicator, a tachometer, an altimeter, an ammeter and the engine cluster. The compass is mounted to the top of the instrument panel in clear view of the pilot.

A complete line of instrument options available for the panel includes a suction gauge, vertical speed indicator, attitude gyro, directional gyro, clock, true speed indicator and a turn and slip indicator or turn coordinator. The attitude gyro and directional gyro are vacuum operated through the use of a vacuum pump installed on the engine, while the turn and slip indicator is electrically operated. The vacuum suction gauge is on the far right of the instrument panel.

*Optional equipment



Instrument Panel

- | | | |
|----------------------------------|----------------------------|-------------------------------|
| 1. CLOCK | 12. UHF TRANSCIVERS | 23. TACHOMETER |
| 2. TURN INDICATOR | 13. SUCTION GAUGE | 24. PRIMER |
| 3. AIRSPEED INDICATOR | 14. CIGAR LIGHTER | 25. MICROPHONE |
| 4. DIRECTIONAL GYRO | 15. MIKE JACK | 26. FRICTION LOCK |
| 5. ATTITUDE GYRO | 16. PHONE JACK | 27. CARBURETOR HEAT CONTROL |
| 6. VERTICAL SPEED INDICATOR | 17. AUTOPILOT | 28. AMMETER GAUGE |
| 7. ALTIMETER | 18. OMNI COUPLER | 29. INSTRUMENT PANEL LIGHTS |
| 8. MAGNETIC COMPASS | 19. MAGNETO/STARTER SWITCH | 30. CIRCUIT BREAKER PANEL |
| 9. OMNI & GLIDE SLOPE INDICATORS | 20. PITCH CONTROL | 31. CIRCUIT BREAKER COVER |
| 10. TRANSPONDER | 21. RPM CRUISE CHART | 32. HEAT & DEFROSTER CONTROLS |
| 11. AUDIO SELECTOR PANEL | 22. INSTRUMENT CLUSTER | 33. THROTTLE QUADRANT |

HDG LOG
 OMNI MURK
 NAV LOC
 BAC

PITOT-STATIC SYSTEM

The system supplies both **pitot** and **static pressure** for the airspeed indicator, altimeter, and the optional vertical speed indicator.

Pitot and static pressure are picked up by a **pitot head** installed on the bottom of the left wing and carried through pitot and static lines within the wing and fuselage to the gauges on the instrument panel.

A **static valve**, which is mounted to the knee guard below the instrument panel on the left side, provides an alternate static source for the system when opened.

Both the pitot and static lines can be drained through separate **drain valves** located on the left lower side of the fuselage interior.

A heated pitot head, which alleviates problems with icing and heavy rain, is available as optional equipment. The switch for the heated pitot head is located on the electrical switch panel to the left of the right control wheel.

To prevent bugs and water from entering the pitot and static pressure holes, a cover should be placed over the pitot head. A partially or completely blocked pitot head will give erratic or zero readings on the instruments.

NOTE

During the preflight, check to make sure the pitot cover is removed.


HEATING AND VENTILATING SYSTEM

Heat for the cabin interior and the defroster system is provided by a shroud attached to the muffler. The amount of heat can be regulated with the controls located on the far right side of the instrument panel.


The airflow between front and rear seats can be regulated by the **heat diversion controls** located on either side of the console atop the heat ducts.

Fresh air inlets are located in the leading edges of the wings on the fin. At each front seat location there is a large adjustable **fresh air outlet** on the side of the cabin near the floor. Rear seat vents are optional. Cabin air is exhausted through an outlet located below the rear seat.

An **optional overhead ventilating system** with outlets over each seat is also available. An additional option to aid in fresh air circulation is a **cabin air blower** to force air through the overhead vent system. This blower is operated by a fan switch with four positions - "OFF," "LOW," "MED," and "HIGH." The switch is located on the right side of the instrument panel with the heater and defroster controls.



Pitot-Static System



Heating and Ventilating System

CHEROKEE WARRIOR

CABIN FEATURES

For ease of entry and exit and for pilot-passenger comfort, the front seats are adjustable fore and aft. The right front seat tilts forward to allow easy entry to the rear seats. The cabin interior includes a pilot storm window, ash trays and armrests on each front seat, two map pockets and pockets on the backs of the front seats.

The front seats can be equipped with optional headrests and optional push button vertical adjustment.

Seat belts are standard equipment for both front and rear seats. The shoulder straps controlled by inertia reels are standard equipment on the front seats and are offered as an option for the rear seats. The shoulder strap is routed over the shoulder adjacent to the window and attached to the seat belt in the general area of the occupants' inboard hip.

A check of the inertia reel mechanism is made by pulling sharply on the strap. The reel should lock in place under this test and prevent the strap from extending. For normal body movements, the strap will extend or retract as required.

BAGGAGE AREA

A 24 cubic foot baggage area, located behind the rear seat, is accessible from the cabin or loaded through a large 20 x 22 inch outside baggage door on the right side of the fuselage. Maximum capacity is 200 pounds. Tie-down straps are available and they should be used at all times.

NOTE

It is the pilot's responsibility to be sure when the baggage is loaded that the aircraft C.G. falls within the allowable C.G. range. (See Weight and Balance Section.)

STALL WARNING

An approaching stall is indicated by an audible alarm located behind the instrument panel. The indicator activates at between five and ten miles per hour above stall speed.


FINISH

All exterior surfaces are primed with etching primer and finished with a durable acrylic lacquer which is available in a variety of colors and combinations. To keep the finish attractive, economy size spray cans of touch-up paint are available from Piper Dealers.

PIPER EXTERNAL POWER*

An optional starting installation known as **Piper External Power (PEP)** is accessible through a receptacle located on the right side of the fuselage aft of the baggage door. An external battery can be connected to the socket, thus allowing the operator to crank the engine without having to gain access to the airplane's battery. Instructions on a placard located on the cover of the receptacle should be followed before using the external power. For instructions on the use of the PEP see; **STARTING WITH EXTERNAL POWER** under the Operating Instructions Section of this manual.


*Optional equipment



AIRPLANE FLIGHT MANUAL

FOR

CHEROKEE WARRIOR



NOTE

THIS MANUAL MUST BE KEPT IN THE AIRPLANE AT ALL TIMES

MANUFACTURER'S MODEL PA-28-151

MANUFACTURER'S SERIAL 28-7415398

REGISTRATION - N 42671

FAA APPROVED BY:

H. W. Barnhouse
H. W. BARNHOUSE
PIPER AIRCRAFT CORPORATION
D. O. A. NO. SO-1
VERO BEACH, FLORIDA

DATE OF APPROVAL: JULY 25, 1973

APPROVAL BASIS: CAR 3 AND FAR PART 21, SUBPART J.

REPORT: VB-573
MODEL: PA-28-151

AIRPLANE FLIGHT MANUAL

Log of Revisions	3-iii
Limitations	3-1
Procedures	3-5
Performance	3-7
Supplements	3-9

TABLE OF CONTENTS

Log of Revisions 3-iii

SECTION I

 Limitations 3-1

 A. Engine 3-1

 B. Fuel 3-1

 C. Propeller 3-1

 D. Power Instruments 3-1

 E. Airspeed Limitations and Airspeed Instrument Markings
 (Calibrated Airspeed) (MPH) 3-2

 F. Maximum Weight 3-2

 G. Baggage Capacity 3-2

 H. C. G. Range 3-2

 I. Maneuvers 3-3

 J. Placards 3-3

SECTION II

 Procedures 3-5

SECTION III

 Performance 3-7

SECTION IV

 Supplements 3-9



 A. Electric Pitch Trim Installation (With Pitch Trim Switch) 3-11

 B. AutoControl III Installation 3-13

 C. AutoFlite II Installation 3-15

THIS PAGE INTENTIONALLY LEFT BLANK

AIRPLANE FLIGHT MANUAL LOG OF REVISIONS

Revision	Revised Pages	Description and Revision	FAA Approved Date
1	All 3-5	Completely revised to printed format for assembly into Pilot's Operating Manual 761 563. Revised spin recovery technique, item 3. c.	 H. W. Barnhouse August 1, 1973
2	3-i 3-1 3-2 3-7 3-9 3-13 3-14 3-15 3-16	Revised Table of Contents Revised Item C. Propeller Limitations Revised Airspeed Range Revised Stall Speed Chart Revised List of Supplements Added page and Supplement B Added page Added page and Supplement C Added page	 H. W. Barnhouse August 30, 1973

THIS PAGE INTENTIONALLY LEFT BLANK

AFMS 1085
AIRPLANE FLIGHT MANUAL SUPPLEMENT
FOR PIPER MODEL PA-28-151 CHEROKEE WARRIOR
MODIFIED IN ACCORDANCE WITH STC SA2969SW

*Installation of
160 HP Textron Lycoming model
O-320-D2A, -D2B, -D2C, -D3G,
or -E3D (modified) Engine and
Sensenich model 74DM6-0-58 or -60 Propeller*

This supplement is FAA approved and must be attached to the FAA-approved Airplane Flight Manual when the aircraft has been modified in accordance with S.T.C. SA2969SW. The information contained in this document supplements or supersedes the Airplane Flight Manual only in those areas listed herein. For limitations, procedures, and performance not contained in this supplement, consult the Airplane Flight Manual.

Approved: _____

A. J. Merrill
A. J. Merrill, Manager ASW-190
Special Certification Office

Date: _____

NOV 12 1997

RAM
AIRCRAFT CORPORATION
P. O. BOX 5219 - WACO, TEXAS 76708
817 / 752 - 8381

LOG OF REVISIONS

Revision	Pages Affected	Description	Approval
—	—	Original Submittal	

FAA APPROVED
DATE: NOV 12 1997



GENERAL

ENGINE

Textron Lycoming model O-320-D2A, -D2B, -D2C, -D3G, or -E3D (modified per STC SE8987SW)

PROPELLER

Sensenich model 74DM6-0-58 or 74DM6-0-60

LIMITATIONS

ENGINE LIMITS

Maximum continuous.....2650 rpm (150 hp)
Take-off (5 minutes).....2700 rpm (160 hp)

PROPELLER LIMITS

Static RPM at maximum throttle setting.....2450 to 2350 rpm
Diameter74.0 to 72.0 inches

ENGINE INSTRUMENT MARKINGS

TACHOMETER

Green arc: 2200 - 2650 rpm
Yellow arc: 2650 - 2700 rpm
Red radial : 2700 rpm

PERFORMANCE

The performance of this airplane, equipped with a Lycoming O-320-D2A, -D2B, -D2C, -D3G, or -E3D (modified per STC SE8987SW) engine, is equal to or better than the original FAA-approved performance.

WEIGHT & BALANCE

No change to center-of-gravity limits.

SECTION I
LIMITATIONS

The following limitations must be observed in the operation of this airplane:

A. ENGINE

Lycoming O-320-E3D

ENGINE LIMITS

For all operations 2700 RPM, 150 HP

B. FUEL

80/87 octane aviation fuel

C. PROPELLER

Sensenich 74DM6, maximum diameter 74 inches. Minimum diameter 72 inches. Static RPM at maximum permissible throttle setting: Not over 2375, not under 2275. No additional tolerance permitted.

McCauley 1C160/EGM7653, maximum diameter 76 inches. Minimum diameter 74.5 inches. Static RPM at maximum permissible throttle setting: Not over 2400, not under 2300. No additional tolerance permitted.

D. POWER INSTRUMENTS

OIL TEMPERATURE

Green Arc (Normal Operating Range)	75° F to 245° F
Red Line (Maximum)	245° F

OIL PRESSURE

Green Arc (Normal Operating Range)	60 PSI to 90 PSI
Yellow Arc (Caution Range)	25 PSI to 60 PSI
Red Line (Minimum)	25 PSI
Red Line (Maximum)	90 PSI

FUEL PRESSURE

Green Arc (Normal Operating Range)	.5 PSI to 8 PSI
Red Line (Minimum)	.5 PSI
Red Line (Maximum)	8 PSI

TACHOMETER

Green Arc (Normal Operating Range)	500 to 2700 RPM
Red Line (Maximum Continuous Power)	2700 RPM

CHEROKEE WARRIOR

E. AIRSPEED LIMITATIONS AND AIRSPEED INSTRUMENT MARKINGS (Calibrated Airspeed)

NEVER EXCEED	176 MPH	<i>V_{NE}</i>
MAXIMUM STRUCTURAL CRUISE	140 MPH	<i>V_{NO}</i>
MANEUVERING	124 MPH	<i>V_A</i>
FLAPS EXTENDED	125 MPH	<i>V_{FE}</i>
MAXIMUM POSITIVE LOAD FACTOR	(Normal Category) 3.8	
MAXIMUM POSITIVE LOAD FACTOR	(Utility Category) 4.4	
MAXIMUM NEGATIVE LOAD FACTOR	No inverted maneuvers approved	

AIRSPEED INSTRUMENT MARKINGS

Red Radial Line (Never Exceed)	176 MPH (153 KTS)
Yellow Arc (Caution Range)	<i>V_{NO}</i> 140 MPH to 176 MPH <i>V_{NE}</i> (122 KTS to 153 KTS)
(Smooth Air Only)	
Green Arc (Normal Operating Range)	<i>V_{SI}</i> 64.5 MPH to 140 MPH <i>V_{NO}</i> (56 KTS to 122 KTS)
White Arc (Flap Down Range)	<i>V_{SO}</i> 58 MPH to 125 MPH <i>V_{FE}</i> (50 KTS to 109 KTS)
<i>Best Glide</i>	<i>V_{GLide} 74 MPH</i>

F. MAXIMUM WEIGHT

Normal Category	2325 LBS
Utility Category	1950 LBS

G. BAGGAGE CAPACITY

200 LBS

H. C. G. RANGE

The datum used is 78.4 inches ahead of wing leading edge at the intersection of the straight and tapered section.

1. Normal Category

Weight (Pounds)	Forward Limit (In. Aft of Datum)	Rearward Limit (In. Aft of Datum)
2325	87.0	93.0
1950	83.0	93.0

2. Utility Category

Weight (Pounds)	Forward Limit (In. Aft of Datum)	Rearward Limit (In. Aft of Datum)
1950	83.0	86.5

Straight line variation between points given.

NOTE

It is the responsibility of the airplane owner and the pilot to insure that the airplane is properly loaded. See Weight and Balance Section for proper loading instructions.

I. MANEUVERS

1. Normal Category - All acrobatic maneuvers including spins prohibited.
2. Utility Category - Approved maneuvers for Utility Category only.

	Entry Speed
Steep Turns	124 MPH
Lazy Eights	124 MPH
Chandelles	124 MPH

J. PLACARDS

In full view of the pilot:

“THIS AIRPLANE MUST BE OPERATED AS A NORMAL OR UTILITY CATEGORY AIRPLANE IN COMPLIANCE WITH THE OPERATING LIMITATIONS STATED IN THE FORM OF PLACARDS, MARKINGS AND MANUALS.

ALL MARKINGS AND PLACARDS ON THIS AIRPLANE APPLY TO ITS OPERATION AS A UTILITY CATEGORY AIRPLANE. FOR NORMAL AND UTILITY CATEGORY OPERATIONS, REFER TO THE AIRPLANE FLIGHT MANUAL.

NO ACROBATIC MANEUVERS ARE APPROVED FOR NORMAL CATEGORY OPERATIONS. SPINS ARE PROHIBITED FOR NORMAL AND UTILITY CATEGORIES.”

In full view of the pilot, the following takeoff and landing check lists will be installed:

TAKEOFF CHECK LIST

Fuel on proper tank	Mixture set	Fasten belts/harness
Electric fuel pump on	Seat backs erect	Trim tab - set
Engine gauges checked		Controls - free
Flaps - set		Door - latched
Carb heat off		

LANDING CHECK LIST

Fuel on proper tank		Flaps - set (125 mph)
Mixture rich	Seat backs erect	Fasten belts/harness
Electric fuel pump on		

CHEROKEE WARRIOR

Adjacent to upper door latch:

"ENGAGE LATCH BEFORE FLIGHT."

On the instrument panel in full view of the pilot:

"DEMONSTRATED CROSSWING COMPONENT 20 MPH."

On inside of the baggage compartment door:

**"BAGGAGE MAXIMUM 200 LBS"
"UTILITY CATEGORY OPERATION - NO BAGGAGE OR
AFT PASSENGERS ALLOWED. NORMAL CATEGORY
OPERATION - SEE AIRPLANE FLIGHT MANUAL WEIGHT
AND BALANCE SECTION FOR BAGGAGE AND AFT
PASSENGER LIMITATIONS."**

In full view of the pilot:

"ROUGH AIR OR MANEUVERING SPEED - 124 MPH."

**"UTILITY CATEGORY OPERATION - NO AFT PASSENGERS
ALLOWED."**

On the instrument panel in full view of the pilot when the oil cooler winterization kit is installed:

**"OIL COOLER WINTERIZATION PLATE TO BE REMOVED
WHEN AMBIENT TEMPERATURE EXCEEDS 50° F."**

In full view of the pilot:

"UTILITY CATEGORY ONLY."

ACROBATIC MANEUVERS ARE LIMITED TO THE FOLLOWING:

	ENTRY SPEED
SPINS PROHIBITED	
STEEP TURNS	124 MPH
LAZY EIGHTS	124 MPH
CHANDELLES	124 MPH

On the instrument panel in full view of the pilot when the supplementary white strobe lights are installed:

**"WARNING - TURN OFF STROBE LIGHTS WHEN TAXIING
IN VICINITY OF OTHER AIRCRAFT, OR DURING FLIGHT
THROUGH CLOUD, FOG OR HAZE."**

SECTION II
PROCEDURES

1. The stall warning system is inoperative with the master switch off.
2. Electric fuel pump must be on for both landing and takeoff.
3. The PA-28-151 airplane is approved under FAA Regulation CAR 3 which prohibits intentional spins for both normal and utility category operation. The following information is noteworthy:
 - a. The stall characteristics of the PA-28-151 are normal with the nose pitching down moderately following the stall, occasionally with a moderate roll which can be corrected by normal use of ailerons and rudder against the roll.
 - b. Prolonged use of full rudder during stall practice may result in a rapid roll followed by a spin and should be avoided. Recovery from an incipient spin may be effected in less than one additional turn by use of opposite rudder followed by full forward control wheel.
 - c. In the event that a fully developed spin is inadvertently experienced, recovery is best made by centering the aileron while using full opposite rudder followed by full forward wheel. The control positions against the spin should be maintained during the entire recovery, which may require several turns and a substantial loss of altitude if the airplane is loaded heavily with a rearward center of gravity.
4. Except as noted above, all operating procedures for this airplane are normal.

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION III
PERFORMANCE

The following performance figures were obtained during FAA type tests and may be realized under conditions indicated with the airplane and engine in good condition and with average piloting technique. All performance is given for 2325 pounds.

Loss of altitude during stalls varied from 100 to 275 feet, depending on configuration and power.

Stalling speeds, in mph, power off, versus angle of bank (Calibrated Airspeed):

Angle of Bank	0°	20°	40°	50°	60°
Flaps Up	64.5 <i>56 KTS</i>	67	74	80	91
Flaps Down	58 <i>50 KTS</i>	60	66	72	82

THIS PAGE INTENTIONALLY LEFT BLANK

SECTION IV
SUPPLEMENTS

NOTE

A FLIGHT MANUAL SUPPLEMENT IS REQUIRED TO BE IN THE AIRPLANE FLIGHT MANUAL ONLY IF THE EQUIPMENT WHICH IS THE SUBJECT OF THE SUPPLEMENT IS INSTALLED.

- A. Electric Pitch Trim Installation (With Pitch Trim Switch)
- B. AutoControl III Installation
- C. AutoFlite II Installation

THIS PAGE INTENTIONALLY LEFT BLANK

A. ELECTRIC PITCH TRIM INSTALLATION (With Pitch Trim Switch)

The following emergency information applies in case of electric pitch trim malfunction:

1. In case of malfunction, disengage electric pitch trim by pushing pitch trim switch on instrument panel to OFF position.
2. In an emergency, electric pitch trim may be overpowered using manual pitch trim.
3. In cruise configuration, malfunction results in 10° pitch change and 200 ft altitude variation.
4. In approach configuration, a malfunction can result in a 5° pitch change and 50 ft altitude loss.

THIS PAGE INTENTIONALLY LEFT BLANK

B. AUTOCONTROL III INSTALLATION

1. LIMITATIONS

- a. Autopilot use is prohibited above 170 MPH-CAS.
- b. Autopilot "OFF" for takeoff and landing.

2. PROCEDURES

a. Normal Operation

Refer to the current AutoControl III Owner's Handbook.

b. Emergency Operation

- (1) In an emergency, the AutoControl III can be disconnected by:
 - (a) Pushing the roll "ON-OFF" switch to "OFF."
 - (b) Turning aircraft Master Switch "OFF."
- (2) The AutoControl III can be overpowered at either control wheel.
- (3) An autopilot runaway, with a 3 second delay in the initiation of recovery, while operating in a climb, cruise or descending flight could result in a 60° bank and a 320 foot altitude loss measured at 170 MPH CAS in a descent.
- (4) An autopilot runaway, with a 1 second delay in the initiation of recovery, during an approach operation, coupled or uncoupled, could result in a 15° bank and a 20 foot altitude loss.

3. PERFORMANCE

The airplane performance remains unchanged.

THIS PAGE INTENTIONALLY LEFT BLANK

C. AUTOFLITE II INSTALLATION

1. LIMITATIONS

- a. Autopilot use is prohibited above 170 MPH-CAS.
- b. Autopilot "OFF" for takeoff and landing.

2. PROCEDURES

a. Normal Operation

Refer to the current AutoFlite II Owner's Handbook.


b. Emergency Operation

- (1) In an emergency, the AutoFlite II can be disconnected by:
 - (a) Pressing disconnect switch on pilot's control wheel.
 - (b) Rocker switch on instrument panel - OFF.
 - (c) Turning aircraft Master Switch "OFF."
- (2) Unit may be overpowered manually at either control wheel.
- (3) An autopilot runaway, with a 3 second delay in the initiation of recovery, while operating in a climb, cruise or descending flight could result in a 60° bank and a 320 foot altitude loss measured at 170 MPH CAS in a descent.
- (4) An autopilot runaway, with a 1 second delay in the initiation of recovery, during an approach operation, coupled or uncoupled, could result in a 15° bank and a 20 foot altitude loss.

3. PERFORMANCE


The airplane performance remains unchanged.

THIS PAGE INTENTIONALLY LEFT BLANK



**F.A.A. APPROVED
EMERGENCY PROCEDURES**

NONE APPLICABLE TO THIS AIRPLANE



EMERGENCY PROCEDURES

Introduction	4-1
Engine Power Loss During Takeoff	4-1
Engine Power Loss In Flight	4-2
Power Off Landing	4-2
Spins	4-3
Open Door	4-3
Fire	4-4
Loss of Oil Pressure	4-5
Loss of Fuel Pressure	4-5
High Oil Temperature	4-5
Alternator Failure	4-6
Engine Roughness	4-6

EMERGENCY PROCEDURES

INTRODUCTION

This section contains procedures that are recommended if an emergency condition should occur during ground operation, takeoff, or in flight. These procedures are suggested as the best course of action for coping with the particular condition described, but are not a substitute for sound judgment and common sense. Since emergencies rarely happen in modern aircraft, their occurrence is usually unexpected, and the best corrective action may not always be obvious. Pilots should familiarize themselves with the procedures given in this section and be prepared to take appropriate action should an emergency arise.

Most basic emergency procedures, such as power off landings, are a part of normal pilot training. Although these emergencies are discussed here, this information is not intended to replace such training, but only to provide a source of reference and review, and to provide information on procedures which are not the same for all aircraft. It is suggested that the pilot review standard emergency procedures periodically to remain proficient in them.

ENGINE POWER LOSS DURING TAKEOFF

The proper action to be taken if loss of power occurs during takeoff will depend on circumstances.

1. If sufficient runway remains for a normal landing, land straight ahead.
2. If insufficient runway remains, maintain a safe airspeed and make only a shallow turn if necessary to avoid obstructions. Use of flaps depends on circumstances. Normally, flaps should be fully extended for touchdown.
3. If you have gained sufficient altitude to attempt a restart, proceed as follows:
 - a. MAINTAIN SAFE AIRSPEED
 - b. FUEL SELECTOR - SWITCH TO ANOTHER TANK CONTAINING FUEL
 - c. ELECTRIC FUEL PUMP - CHECK ON
 - d. MIXTURE - CHECK RICH
 - e. CARBURETOR HEAT - ON

NOTE

If engine failure was caused by fuel exhaustion, power will not be regained after tanks are switched until empty fuel lines are filled, which may require up to ten seconds.

If power is not regained, proceed with the POWER OFF LANDING procedure.

ENGINE POWER LOSS IN FLIGHT

Complete engine power loss is usually caused by fuel flow interruption, and power will be restored shortly after fuel flow is restored. If power loss occurs at low altitude, the first step is to prepare for an emergency landing (See POWER OFF LANDING). Maintain an airspeed of at least 85 MPH, and if altitude permits, proceed as follows:

1. Fuel Selector - Switch to another tank containing fuel.
2. Electric Fuel Pump - On
3. Mixture - Rich
4. Carburetor Heat - On
5. Engine Gauges - Check for indication of the cause of power loss.
6. Primer - Check locked
7. If no fuel pressure is indicated, check tank selector position to be sure it is on a tank containing fuel.

When power is restored:

8. Carburetor Heat - Off
9. Electric Fuel Pump - Off

If the above steps do not restore power, prepare for an emergency landing.

If time permits:

1. Ignition Switch - "L" then "R" then back to "BOTH."
2. Throttle and Mixture - Different settings. (This may restore power if the problem is too rich or too lean a mixture, or partial fuel system restriction.)
3. Try another fuel tank. (Water in the fuel could take some time to be used up, and allowing the engine to windmill may restore power. If power loss is due to water, fuel pressure indications will be normal.)

NOTE

If engine failure was caused by fuel exhaustion, power will not be restored after tanks are switched until empty fuel lines are filled, which may require up to ten seconds.

If power is not restored, proceed with POWER OFF LANDING procedure.

POWER OFF LANDING

If loss of power occurs at altitude, trim the aircraft for best gliding angle 85 MPH, and look for a suitable field. If measures taken to restore power are not effective, and if time permits, check your charts for airports in the immediate vicinity; it may be possible to land at one if you have sufficient altitude. If possible, notify the FAA by radio of your difficulty and intentions. If another pilot or passenger is aboard, let them help.

When you have located a suitable field, establish a spiral pattern around this field. Try to be 1000 feet above the field at the downwind position to make a normal approach. When the field can easily be reached, slow up to 76 MPH for the shortest landing. Excess altitude may be lost by widening your pattern, using flaps or slipping, or a combination of these.

Touchdowns should normally be made at the lowest possible airspeed, with full flaps.

When committed to landing:

1. Ignition - Off
2. Master Switch - Off
3. Fuel Selector - Off
4. Mixture - Idle Cut-Off
5. Seat Belt tight and Shoulder Harness in place.

SPINS

Intentional spins are prohibited in this aircraft. If a spin is inadvertently entered, immediately use the following recovery procedures:

1. THROTTLE - IDLE
2. RUDDER - FULL OPPOSITE TO DIRECTION OF ROTATION
3. CONTROL WHEEL - FULL FORWARD
4. RUDDER - NEUTRAL (WHEN ROTATION STOPS)
5. CONTROL WHEEL - AS REQUIRED TO SMOOTHLY REGAIN LEVEL FLIGHT ATTITUDE

OPEN DOOR

The cabin door on the Cherokee Warrior is double latched, so the chances of it springing open in flight at both the top and bottom are remote. However, should you forget the upper latch, or not engage the lower latch, the door may spring partially open. This will usually happen at takeoff or soon afterward. An open door will not affect normal flight characteristics, and a normal landing can be made with the door open.

If both upper and lower latches open, the door will trail slightly open, and airspeed will be reduced slightly.

To close the door in flight, proceed as follows:

1. Slow aircraft to 100 MPH. - 87 KTS
2. Cabin Vents - Close
3. Storm Window - Open
4. If upper latch is open - latch. If lower latch is open - open top latch, push door further open, and then close rapidly. Latch top latch.

A slip in the direction of the open door will assist in latching procedure.

FIRE

The presence of fire is noted through smoke, smell, and heat in the cabin. It is essential that the source of the fire be promptly identified through instrument readings, character of the smoke, or other indications, since the action to be taken differs somewhat in each case.

1. Source of Fire - Check
 - a. Electrical Fire (Smoke in Cabin):
 - (1) Master Switch - Off
 - (2) Vents - Open
 - (3) Cabin Heat - Off
 - (4) Land as soon as practicable.
 - b. Engine Fire:
 - (1) In case of engine fire in flight
 - (a) Fuel Selector - OFF
 - (b) Throttle - CLOSE
 - (c) Mixture - IDLE CUT OFF
 - (d) Heater - Off (In all cases of fire)
 - (e) Defroster - OFF (In all cases of fire)
 - (f) If terrain permits - Land Immediately

The possibility of an engine fire in flight is extremely remote. The procedure given above is general and pilot judgment should be the deciding factor for action in such an emergency.

- (2) In case of engine fire on the ground
 - (a) If engine has not started
 1. Mixture - IDLE CUT-OFF
 2. Throttle - OPEN
 3. Turn engine with starter (This is an attempt to pull the fire into the engine.)
 - (b) If engine has already started and is running, continue operating to try pulling the fire into the engine.
 - (c) In either case stated in (a) and (b), if the fire continues longer than a few seconds, the fire should be extinguished by the best available external means.
 - (d) If external fire extinguishing is to be applied
 1. Fuel Selector Valve - OFF
 2. Mixture - IDLE CUT-OFF

LOSS OF OIL PRESSURE

Loss of oil pressure may be either partial or complete. A partial loss of oil pressure usually indicates a malfunction in the oil pressure regulating system, and a landing should be made as soon as possible to investigate the cause and prevent engine damage.

A complete loss of oil pressure indication may signify oil exhaustion or may be the result of a faulty gauge. In either case, proceed toward the nearest airport, and be prepared for a forced landing. If the problem is not a pressure gauge malfunction, the engine may stop suddenly. Maintain altitude until such time as a dead stick landing can be accomplished. Don't change power settings unnecessarily, as this may hasten complete power loss.

Depending on the circumstances, it may be advisable to make an off airport landing while power is still available, particularly if other indications of actual oil pressure loss, such as sudden increase in temperatures, or oil smoke, are apparent, and an airport is not close.

If engine stoppage occurs, proceed to **POWER OFF LANDING**.

LOSS OF FUEL PRESSURE

1. Electric Boost Pump - On
2. Fuel Selector - Check on full tank

If problem is not an empty fuel tank, land as soon as practical and have the fuel system checked.

HIGH OIL TEMPERATURE

An abnormally high oil temperature indication may be caused by a low oil level, an obstruction in the oil cooler, damaged or improper baffle seals, a defective gauge, or other causes. Land as soon as practical at an appropriate airport and have the cause investigated.

A steady, rapid rise in oil temperature is a sign of trouble. Land at the nearest airport and let a mechanic investigate the problem. Watch the oil pressure gauge for an accompanying loss of pressure.

ALTERNATOR FAILURE

Loss of alternator output is detected through a zero reading on the ammeter. Before executing the following procedure, insure that the reading is zero and not merely low by actuating an electrically powered device, such as the landing light. If no increase in the ammeter reading is noted, alternator failure can be assumed.

1. Reduce electrical load.
2. Alternator Circuit Breakers - Check
3. "Alt" Switch - Off (for 1 second), then On

If the ammeter continues to indicate no output, or alternator will not stay reset, turn off "Alt" switch, maintain minimum electrical load, and land as soon as practical. All electrical power is being supplied by the battery.

ENGINE ROUGHNESS

Engine roughness is usually due to carburetor icing which is indicated by a drop in RPM, and may be accompanied by a slight loss of airspeed or altitude. If too much ice is allowed to accumulate, restoration of full power may not be possible; therefore, prompt action is required.

1. Carburetor heat - on (See Note). RPM will decrease slightly and roughness will increase. Wait for a decrease in engine roughness or an increase in RPM, indicating ice removal. If no change in approximately one minute, return carburetor heat to OFF. If the engine is still rough, try steps below.
 - a. Mixture - Adjust for maximum smoothness. Engine will run rough if too rich or too lean.
 - b. Electric Fuel Pump - On
 - c. Fuel Selector - Change to other tank to see if fuel contamination is the problem.
 - d. Engine Gauges - Check for abnormal readings. If any gauge readings are abnormal, proceed accordingly.
 - e. Magneto Switch - "L" then "R" then back to "BOTH." If operation is satisfactory on either magneto, proceed on that magneto at reduced power, with mixture full rich, to a landing at the first available airport.

If roughness persists, prepare for a precautionary landing at pilot's discretion.

NOTE

Partial carburetor heat may cause partial melting of ice which will refreeze in the intake system; therefore when using carburetor heat, always use full heat and when ice is removed return to the full cold position.

WEIGHT AND BALANCE

WEIGHT AND BALANCE
FOR
CHEROKEE WARRIOR

28-7415398

N42671

MODEL - PA-28-151

ISSUED: MAY 14, 1973

REPORT: VB-535
MODEL: PA-28-151

WEIGHT AND BALANCE

Log of Revisions	5-iii
Weight and Balance	5-1
Weight and Balance Data - Weighing Procedure	5-3
Weight and Balance Data	5-7
C. G. Range and Weight Instructions	5-8
Equipment List	5-11

INDEX - WEIGHT AND BALANCE

Log of Revisions	5-iii
Weight and Balance	5-1
Weight and Balance Data - Weighing Procedure	5-3
Weight and Balance Data	5-7
C. G. Range and Weight Instructions	5-8
Equipment List	5-11
A. Propeller and Propeller Accessories	5-11
B. Engine and Engine Accessories	5-12
C. Landing Gear and Brakes	5-13
D. Electrical Equipment	5-14
E. Instrument	5-15
F. Miscellaneous	5-16
G. Engine and Engine Accessories (Optional Equipment)	5-17
H. Electrical Equipment (Optional Equipment)	5-18
I. Instruments (Optional Equipment)	5-20
J. Autopilots (Optional Equipment)	5-21
K. Radio Equipment (Optional Equipment)	5-22
L. Miscellaneous (Optional Equipment)	5-26

WEIGHT AND BALANCE LOG OF REVISIONS

Revision	Revised Pages	Description and Revision	Approved Date
1	5-8	Revised Arm and Moment values and Fuel capacity for Sample Loading Problem.	<i>V. Tennant</i> Aug. 30, 1973
2	5-10 5-17 5-27	Revised C.G. Range and Weight Chart. Added Vacuum Pump (79399-0). Revised Ground Ventilating Blower.	<i>[Signature]</i> Jan. 25, 1974

THIS PAGE INTENTIONALLY LEFT BLANK

WEIGHT AND BALANCE

In order to achieve the performance, safety and good flying characteristics which are designed into the airplane, it must be flown with the weight and center of gravity (C.G.) position within the approved envelope. The aircraft offers a tremendous flexibility of loading. However, you cannot fill the airplane, with the maximum number of adult passengers, full fuel tanks and maximum baggage. With the flexibility comes responsibility. The pilot must ensure that the airplane is loaded within the loading envelope before he makes a takeoff.

Misloading carries consequences for any aircraft. An overloaded airplane will not take off, climb or cruise as well as a properly loaded one. The heavier the airplane is loaded, the less climb performance it will have.

Center of gravity is a determining factor in flight characteristics. If the C.G. is too far forward in any airplane, it may be difficult to rotate for takeoff or landing. If the C.G. is too far aft, the airplane may rotate prematurely on takeoff or try to pitch up during climb. Longitudinal stability will be reduced. This can lead to inadvertent stalls and even spins; and spin recovery becomes more difficult as the center of gravity moves aft of the approved limit.

A properly loaded aircraft, however, will perform as intended. This airplane is designed to provide excellent performance and safety within the flight envelope. Before the airplane is delivered, it is weighed, and a basic weight and C.G. location is computed. (Basic weight consists of the empty weight of the aircraft plus the unusable fuel and full oil capacity.) Using the basic weight and C.G. location, the pilot can easily determine the weight and C.G. position for the loaded airplane by computing the total weight and moment and then determining whether they are within the approved envelope.

The basic weight and C.G. location for a particular airplane are recorded in the aircraft log book or in the weight and balance section of the Airplane Flight Manual. The current values should always be used. Whenever new equipment is added or any modification work is done, the mechanic responsible for the work is required to compute a new basic weight and basic C.G. position and to write these in the aircraft log book. The owner should make sure that it is done.

A weight and balance calculation can be helpful in determining how much fuel or baggage can be boarded so as to keep the C.G. within allowable limits. If it is necessary to remove some of the fuel to stay within maximum allowable gross weight, the pilot should not hesitate to do so.

The following pages are forms used in weighing an airplane in production and in computing basic weight, basic C.G. position, and useful load. Note that the useful load includes fuel, oil, baggage, cargo and passengers. Following this is the method for computing takeoff weight and C.G.

THIS PAGE INTENTIONALLY LEFT BLANK

WEIGHT AND BALANCE DATA

WEIGHING PROCEDURE

At the time of delivery, Piper Aircraft Corporation provides each airplane with the licensed empty weight and center of gravity location. This data is on Page 5-7.

The removal or addition of an excessive amount of equipment or excessive airplane modifications can affect the licensed empty weight and empty weight center of gravity. The following is a weighing procedure to determine this licensed empty weight and center of gravity location:

1. PREPARATION

- a. Be certain that all items checked in the airplane equipment list are installed in the proper location in the airplane.
- b. Remove excessive dirt, grease, moisture, foreign items such as rags and tools, from the airplane before weighing.
- c. Defuel airplane. Then open all fuel drains until all remaining fuel is drained. Operate engine on each tank until all undrainable fuel is used and engine stops.
- d. Drain all oil from the engine, by means of the oil drain, with the airplane in ground attitude. This will leave the undrainable oil still in the system. Engine oil temperature should be in the normal operating range before draining.
- e. Place pilot and copilot seats in fourth (4th) notch, aft of forward position. Put flaps in the fully retracted position and all control surfaces in the neutral position. Tow bar should be in the proper location and all entrance and baggage doors closed.
- f. Weigh the airplane inside a closed building to prevent errors in scale readings due to wind.

2. LEVELING

- a. With airplane on scales, block main gear oleo pistons in the fully extended position.
- b. Level airplane (see diagram) deflating nose wheel tire, to center bubble on level.

CHEROKEE WARRIOR


3. WEIGHING - AIRPLANE EMPTY WEIGHT

- a. With the airplane level and brakes released, record the weight shown on each scale. Deduct the tare, if any, from each reading.

Scale Position and Symbol	Scale Reading	Tare	Net Weight
Nose Wheel (N)			
Right Main Wheel (R)			
Left Main Wheel (L)			
Airplane Empty Weight, as Weighed (T)			

4. EMPTY WEIGHT CENTER OF GRAVITY

- a. The following geometry applies to the PA-28-151 airplane when airplane is level (See Item 2).



A =
B =

The datum is 78.4 inches ahead of the wing leading edge at the intersection of the straight and tapered section.

- b. Obtain measurement "A" by measuring from a plumb bob dropped from one wing leading edge, at the intersection of the straight and inboard tapered section, horizontally and parallel to the airplane centerline, to the main wheel centerline.
- c. Obtain measurement "B" by measuring the distance from the main wheel centerline, horizontally and parallel to the airplane centerline, to each side of the nose wheel axle. Then average the measurements.
- d. The empty weight center of gravity (as weighed including optional equipment and undrainable oil) can be determined by the following formula:

$$C.G. \text{ Arm} = 78.4 + A - \frac{B(N)}{T}$$

$$C. G. \text{ Arm} = 78.4 + (\quad) - \frac{(\quad)(\quad)}{(\quad)} = \quad \text{inches}$$

5. LICENSED EMPTY WEIGHT AND EMPTY WEIGHT CENTER OF GRAVITY

	Weight	Arm	Moment
Empty Weight (as weighed)			
Unusable Fuel (2.0 gal.)	12 lb	103.0	1136
Licensed Empty Weight			

THIS PAGE INTENTIONALLY LEFT BLANK

- b. Obtain measurement "A" by measuring from a plumb bob dropped from one wing leading edge, at the intersection of the straight and inboard tapered section, horizontally and parallel to the airplane centerline, to the main wheel centerline.
- c. Obtain measurement "B" by measuring the distance from the main wheel centerline, horizontally and parallel to the airplane centerline, to each side of the nose wheel axle. Then average the measurements.
- d. The empty weight center of gravity (as weighed including optional equipment and undrainable oil) can be determined by the following formula:

$$C.G. \text{ Arm} = 78.4 + A - \frac{B(N)}{T}$$

$$C. G. \text{ Arm} = 78.4 + (\quad) - \frac{(\quad)(\quad)}{(\quad)} = \quad \text{inches}$$

5. LICENSED EMPTY WEIGHT AND EMPTY WEIGHT CENTER OF GRAVITY

	Weight	Arm	Moment
Empty Weight (as weighed)			
Unusable Fuel (2.0 gal.)	12 lb	103.0	1136
Licensed Empty Weight			



MAJOR REPAIR AND ALTERATION (Airframe, Powerplant, Propeller, or Appliance)

Form Approved
OMB No. 2120-0020
2/28/2011

Electronic Tracking Number

For FAA Use Only

INSTRUCTIONS: Print or type all entries. See Title CFR §43.9, Part 43 Appendix B, and AC 43.9-1 (or subsequent revision thereof) for instructions and disposition of this form. This report is required by law (49 U.S.C. §44701). Failure to report can result in a civil penalty for each such violation (49 U.S.C. §46301(a)).

1. Aircraft	Nationality and Registration Mark N42671	Serial No. 28-7415398		
	Make Piper	Model PA-28-151	Series	
2. Owner	Name (As shown on registration certificate) COPELAND, Keith H.		Address (As shown on registration certificate)	
			Address 3454 Agree Lane	
			City Lancaster	State SC
			Zip 29720	Country USA

3. For FAA Use Only

4. Type		5. Unit Identification			
Repair	Alteration	Unit	Make	Model	Serial No.
<input type="checkbox"/>	<input checked="" type="checkbox"/>	AIRFRAME	_____	(As described in item 1 above)	_____
<input type="checkbox"/>	<input type="checkbox"/>	POWERPLANT			
<input type="checkbox"/>	<input type="checkbox"/>	PROPELLER			
<input type="checkbox"/>	<input type="checkbox"/>	APPLIANCE	Type		
			Manufacturer		

6. Conformity Statement

A. Agency's Name and Address		B. Kind of Agency	
Name James B. Kirk	Address 1007 Kir Air Base Rd City Lancaster State SC Zip 29720 Country USA	<input checked="" type="checkbox"/> U.S. Certificated Mechanic	Manufacturer
		<input type="checkbox"/> Foreign Certificated Mechanic	C. Certificate No. 1761726 A&P
		<input type="checkbox"/> Certificated Repair Station	
		<input type="checkbox"/> Certificated Maintenance Organization	

D. I certify that the repair and/or alteration made to the unit(s) identified in item 5 above and described on the reverse or attachments hereto have been made in accordance with the requirements of Part 43 of the U.S. Federal Aviation Regulations and that the information furnished herein is true and correct to the best of my knowledge.

Extended range fuel per 14 CFR Part 43 App. B <input type="checkbox"/>	Signature/Date of Authorized Individual <i>James B. Kirk</i> 28 Dec 2016
--	---

7. Approval for Return To Service

Pursuant to the authority given persons specified below, the unit identified in item 5 was inspected in the manner prescribed by the Administrator of the Federal Aviation Administration and is APPROVED REJECTED

BY	FAA Fit. Standards Inspector	Manufacturer	Maintenance Organization	Persons Approved by Canadian Department of Transport
	FAA Designee	Repair Station	<input checked="" type="checkbox"/> Inspection Authorization	Other (Specify)

Certificate or Designation No. 1761726 IA	Signature/Date of Authorized Individual <i>James B. Kirk</i> James B. Kirk 28 Dec 2016
--	---

NOTICE

Weight and balance or operating limitation changes shall be entered in the appropriate aircraft record. An alteration must be compatible with all previous alterations to assure continued conformity with the applicable airworthiness requirements.

8. Description of Work Accomplished

(If more space is required, attach additional sheets. Identify with aircraft nationality and registration mark and date work completed.)

N42671

Nationality and Registration Mark

28 Dec 2016

Date

1. Remove inoperative Piper Automatic Locator (ELT) and attaching hardware at station 237.0.
2. Install used servicable ACK-450, S/N: 50553 and its attaching hardware at station 152.0.
3. New Empty C.G. at 87.16, New Empty Weight: 1478.8 lbs., New Moment: 128,898.4

_____ END _____

Additional Sheets Are Attached

WEIGHT AND BALANCE REVISION

MAKE: Piper

MODEL: PA28-151

SERIAL#: 28-7415398

REGISTRATION: N42671

EQUIPMENT CHANGE

Computing New C.G.

Item, Make and Model *	Weight	Arm	Moment
1478 @ 87.48	1478	87.48	129,295.44
Equipment Removed Piper - Garrett ELT	-1.9	237	-4503
Equipment Installed ACK-450 ELT	2.7	152	+4104
NEW TOTALS	1478.8	87.16	128,896.44

* ITEM NUMBERS WHEN LISTED IN THE PERTINENT AIRCRAFT SPECIFICATION MAY BE USED IN LIEU OF "ITEM, MAKE, AND MODEL"

Gross Weight: 1478
 New empty weight: 1478.8
 New Center of gravity: 87.16
 Moment: 128,896.44
 Useful load: ~~1478~~ 946.2

Prepared By JAMES B. KIRK Date 12/28/2016

Weight and Balance Report

MAKE: Piper MODEL: PA-28-151 S/N: 28-7415398 REGISTRATION#: N42671

Datum is: Nose of aircraft, 78.4" ahead of wing leading edges

1. Leveling: Leveling Points on left side of fuselage
2. Main wheel weighing point is 110.025 inches aft of Datum.
3. Actual measured distance from main weight point to nose weight point is 78.625 inches.
4. Date of scale calibration: 21 Jun 2000

Actual Weight / Full Fuel

5. Right: 645 lbs.
6. Left: 636 lbs.
7. Nose: 485 lbs.
8. Total: 1766 lbs.
9. C.G. relative to main wheel weighing point:
C.G. = $\frac{\text{Item 3} \times \text{Item 7}}{\text{Item 8}} = \underline{21.592}$ inches forward of main wheel
10. C.G. relative to datum:
C.G. = $\text{Item 2} - \text{Item 9} = \underline{88.43}$ inches aft of datum
11. A/C Total weight: 1766 @ 88.43 = 156,167.4 Moment
12. Remove fuel weight: $\frac{-288}{1478 \text{ lbs.}}$ = $\frac{-26,864}{129,303.4}$ Moment

Actual Empty Weight


13. Aircraft Empty Weight: 1478 Lbs.
14. C.G.: 87.48 inches aft of datum / 129,303.4 Moment

Date: 21 Jun 2000


James B. Kirk A&P/IA 1761726

James B. Kirk

LOADING GRAPH



C. G. RANGE AND WEIGHT



A = With Max baggage (190 lbs)

WEIGHT AND BALANCE DATA

MODEL PA-28-151 CHEROKEE

Airplane Serial Number 28-7415398

Registration Number N42671

Date April 3, 1974

AIRPLANE EMPTY WEIGHT

Item		Weight (Lbs)	× C. G. Arm (Inches Aft of Datum)	= Moment (In-Lbs)
*Empty Weight	XXXXXX Computed	1315.0 1317.0	85.6 85.6	112499 112726
Unusable Fuel (2 gal.)		12	103	1136
Standard Empty Weight		1327.0	85.6	113635
Optional Equipment		159.1	101.7	16175
Licensed Empty Weight		1486.1	87.3	129810

*Empty weight is defined as dry empty weight (including paint and hydraulic fluid) plus 1.8 lbs undrainable engine oil.

AIRPLANE USEFUL LOAD

(Gross Weight) - (Licensed Empty Weight) = Useful Load

Normal Category:	(2325 lbs)	-	(1486.1 lbs)	= 838.9 ^{836.9} lbs
Utility Category:	(1950 lbs)	-	(1486.1 lbs)	= 463.9 ^{463.9} lbs

THIS LICENSED EMPTY WEIGHT, C. G. AND USEFUL LOAD ARE FOR THE AIRPLANE AS DELIVERED FROM THE FACTORY. REFER TO APPROPRIATE AIRCRAFT RECORD WHEN ALTERATIONS HAVE BEEN MADE.

C. G. RANGE AND WEIGHT INSTRUCTIONS

1. Add the weight of all items to be loaded to the licensed empty weight.
2. Use the loading graph to determine the moment of all items to be carried in the airplane.
3. Add the moment of all items to be loaded to the licensed empty weight moment.
4. Divide the total moment by the total weight to determine the C.G. location.
5. By using the figures of Item 1 and Item 4, locate a point on the C.G. range and weight graph. If the point falls within the C.G. envelope, the loading meets the weight and balance requirements.

SAMPLE LOADING PROBLEM (Normal Category)

	Weight (Lbs)	Arm Aft Datum (Inches)	Moment (In-Lbs)
Licensed Empty Weight	1478	87.48	129,303.4
Oil (8 quarts) <i>(included above)</i>	-	-	-
Pilot and Front Passenger	340	80.5	27370
Passengers, Aft* (Rear Seat)	340	118.1	40154
Fuel (48 Gal. Maximum)	167	95.	16,000
Baggage*		142.8	
Total Loaded Airplane	2325	91.5	212,827

The center of gravity (C.G.) of this sample loading problem is at 90.9 inches aft of the datum line. Locate this point (90.9) on the C.G. range and weight graph. Since this point falls within the weight - C.G. envelope, this loading meets the weight and balance requirements.

IT IS THE RESPONSIBILITY OF THE PILOT AND AIRCRAFT OWNER TO INSURE THAT THE AIRPLANE IS LOADED PROPERLY.

*Utility Category Operation - No baggage or aft passengers allowed.

TRI-CITY AVIATION, Inc.

The Full Service Stop

Flight Instruction - Charter - Maintenance - Aircraft Sales

TRI-CITY AIRPORT

BOX 5155

KINGSPORT, TENN. 37663

PHONE 615 - 323-6261

June 1, 1988

PA-28-151

N42671

S/N 28-7415398

*See
21 JUL 2000*

EQUIPMENT LIST- WEIGHT & BALANCE DATA

	<u>Weight</u>	<u>Arm</u>	<u>Moment</u>
Removed: Standard Brake Disc, Left/Right	4.0	109.6	438.4
Installed: Stainless Brake Disc, STC SA174550	4.0	109.6	438.4

NOTE: No weight change per this data. See aircraft weight & balance sheets.

Michael C. Lloyd

Michael C. Lloyd
IA415869827



U.S. Department of Transportation
Federal Aviation Administration

MAJOR REPAIR AND ALTERATION (Airframe, Powerplant, Propeller, or Appliance)

Form Approved OMB No. 2120-0020 2/28/2011	Electronic Tracking Number
For FAA Use Only	

INSTRUCTIONS: Print or type all entries. See Title CFR §43.9, Part 43 Appendix B, and AC 43.9-1 (or subsequent revision thereof) for instructions and disposition of this form. This report is required by law (49 U.S.C. §44701). Failure to report can result in a civil penalty for each such violation (49 U.S.C. §46301(a)).

1. Aircraft	Nationality and Registration Mark N42671	Serial No. 74-15398	
	Make Piper	Model PA-28-151	Series
2. Owner	Name (As shown on registration certificate) COPELAND, Keith H.	Address (As shown on registration certificate) Address 3454 Agree Lane	
		City Lancaster	State SC
		Zip 29720	Country USA

3. For FAA Use Only

4. Type		5. Unit Identification			
Repair	Alteration	Unit	Make	Model	Serial No.
<input checked="" type="checkbox"/>	<input type="checkbox"/>	AIRFRAME	_____	(As described in item 1 above)	_____
<input type="checkbox"/>	<input type="checkbox"/>	POWERPLANT			
<input type="checkbox"/>	<input type="checkbox"/>	PROPELLER			
<input type="checkbox"/>	<input type="checkbox"/>	APPLIANCE	Type _____		
			Manufacturer _____		

6. Conformity Statement

A. Agency's Name and Address		B. Kind of Agency	
Name James B. Kirk		<input checked="" type="checkbox"/> U.S. Certificated Mechanic	
Address 1007 Kirk Air Base Rd		<input type="checkbox"/> Foreign Certificated Mechanic	C. Certificate No.
City Lancaster State SC		<input type="checkbox"/> Certificated Repair Station	1761726 A&P
Zip 29720 Country USA		<input type="checkbox"/> Certificated Maintenance Organization	

D. I certify that the repair and/or alteration made to the unit(s) identified in item 5 above and described on the reverse or attachments hereto have been made in accordance with the requirements of Part 43 of the U.S. Federal Aviation Regulations and that the information furnished herein is true and correct to the best of my knowledge.

Extended range fuel per 14 CFR Part 43 App. B <input type="checkbox"/>	Signature/Date of Authorized Individual <i>James B. Kirk</i>	1 Nov 2010
--	---	------------

7. Approval for Return To Service

Pursuant to the authority given persons specified below, the unit identified in item 5 was inspected in the manner prescribed by the Administrator of the Federal Aviation Administration and is APPROVED REJECTED

BY	FAA Ft. Standards Inspector	Manufacturer	Maintenance Organization	Person Approved by Canadian Department of Transport
	FAA Designee	Repair Station	<input checked="" type="checkbox"/> Inspection Authorization	Other (Specify)

Certificate or Designation No. 1761726 IA	Signature/Date of Authorized Individual <i>James B. Kirk</i>	James B. Kirk 1 Nov 2010
--	---	--------------------------

NOTICE

Weight and balance or operating limitation changes shall be certified in the appropriate aircraft record. An alteration must be compatible with all previous alterations to ensure continued conformity with the applicable airworthiness requirements.

8. Description of Work Accomplished

(If more space is required, attach additional sheets. Identify with aircraft nationality and registration mark and date work completed.)

N42671

Nationality and Registration Mark

1 Nov 2010

Date

1. Replace leading edge skin - right side, P/N: 35118-47. The section of leading edge was damaged (dented) by airport mowing equipment.
2. Replace top center cowling panel skin, (P/N: 35555-00) due to fatigue cracks at each of the corners. Previously repaired, but were repaired corners were cracking again. Fabricated new skin from 2024-T3 aluminum of .032 thickness.
3. Installed by riveting I. A. W. AC43.13-1B/2A, dated Sep 1998, para. 4-57 (Riveting), 4-58 (Repair methods & precautions for aluminum structure) and Piper Maintenance Manual for PA-28-151 "Warrior" aircraft.
4. Weight and balance was not effected by these repairs.
5. NOTHING FOLLOWS

Additional Sheets Are Attached



U.S. Department
of Transportation
Federal Aviation
Administration

MAJOR REPAIR AND ALTERATION (Airframe, Powerplant, Propeller, or Appliance)

Form Approved OMB
No. 2120-0020

For FAA Use Only

Office Identification

INSTRUCTIONS: Print or type all entries. See FAR 43.9, FAR 43 Appendix B, and AC 43.9-1 (or subsequent revision thereof) for instructions and disposition of this form. This report is required by law (49 U.S.C. 1421). Failure to report can result in a civil penalty not to exceed \$1,000 for each such violation (Section 901 Federal Aviation Act 1958)

1. Aircraft	Make Piper Serial No. 28-7415398	Model PA-28-151 Nationality and Registration Mark N42671
2. Owner	Name (As shown on registration certificate) COPELAND, Keith H. KRIMMINGER, Michiel	Address (As shown on registration certificate) 3454 Agree Lane Lancaster, SC 29720-9370

3. For FAA Use Only

4. Unit Identification				5. Type	
Unit	Make	Model	Serial No.	Repair	Alteration
AIRFRAME	----- (As described in Item 1 above) -----				X
POWERPLANT					
PROPELLER					
APPLIANCE	Type				
	Manufacturer				

6. Conformity Statement

A. Agency's Name and Address James B. Kirk 1007 Kirk Air Base Rd. Lancaster, SC 29720-8699	B. Kind of Agency <input checked="" type="checkbox"/> U.S. Certificated Mechanic <input type="checkbox"/> Foreign Certificated Mechanic <input type="checkbox"/> Certificated Repair Station <input type="checkbox"/> Manufacturer	C. Certificate No. A&P1761726
--	---	---

D. I certify that the repair and/or alteration made to the unit(s) identified in item 4 above and described on the reverse or attachments hereto have been made in accordance with the requirements of Part 43 of the U.S. Federal Aviation Regulations and that the information furnished herein is true and correct to the best of my knowledge.

Date 21 Jun 2000	Signature of Authorized Individual
---------------------	--

7. Approval for Return To Service

Pursuant to the authority given persons specified below, the unit identified in item 4 was inspected in the manner prescribed by the Administrator of the Federal Aviation Administration and is APPROVED REJECTED

BY	FAA Fit Standards Inspector	Manufacturer	<input checked="" type="checkbox"/>	Inspection Authorization	Other (Specify)
	FAA Designee	Repair Station		Person Approved by Transport Canada Airworthiness Group	

Date of Approval or Rejection 21 Jun 2000	Certificate or Designation No. IA1761726	Signature of Authorized Individual
--	---	--

NOTICE

Weight and balance or operating limitation changes shall be entered in the appropriate aircraft record. An alteration must be compatible with all previous alterations to assure continued conformity with the applicable airworthiness requirements.

B. Description of Work Accomplished

(If more space is required, attach additional sheets. Identify with aircraft nationality and registration mark and date work completed.)

1. Replace #1 Nav/Comm King KX-170B with Michel MX-170B, (S/N: 4113).
2. Remove #1 Nav Indicator, King KI-214 VOR/ILS/GS Indicator.
3. Install #1 Nav Indicator, King KI-209 VOR/ILS/GS Indicator, P/N: 066-3056-01, (S/N: 5019).
4. Install King KN-75 Glide Slope receiver, (S/N: 4155), installation accordance with AlliedSignal Installation Manual #006-00150-0001, Rev 1, July 1978. Unit installed aft of baggage compartment on avionics compartment floor.
5. Replace Air Path compass with PAI-700 Vertical Card compass, (S/N: 38564).
6. Install PS Engineering, Inc. SPA-400 Intercom, 4 place system.
7. All equipment was installed IAW with manufacturer's installation manuals and AC43.13-1B, Chapters 11 and 12, and AC43.13-2A, Chapters 1 and 2.
8. PAI-700 Compass swung IAW AC43.13-1B, Chapter 12-37.
9. An electrical load analysis has been made and it has been determined that the load does not exceed 80% of the rated alternator capacity.
10. A flight test was performed on the Michel MX-170B Nav/Com installation, performance is acceptable for VFR flight conditions at this time.
11. Weight & balance has been performed and the result recorded in the aircraft's permanent record.

***** End Report *****

Additional Sheets Are Attached

MAJOR REPAIR AND ALTERATION
(Airframe, Powerplant, Propeller, or Appliance)

FOR FAA USE ONLY
OFFICE IDENTIFICATION

INSTRUCTIONS: Print or type all entries. See FAR 43.9, FAR 43 Appendix B, and AC 43.9-1 (or subsequent revision thereof) for instructions and disposition of this form.

1. AIRCRAFT	MAKE Piper	MODEL PA-28-151
	SERIAL NO. 28-7415398	NATIONALITY AND REGISTRATION MARK N42761
2. OWNER	NAME (As shown on registration certificate) Wesley, Arnold A. Wesley, Gloria A.	ADDRESS (As shown on registration certificate) 350 Kathleen Drive Jefferson, OH 44047

3. FOR FAA USE ONLY

4. UNIT IDENTIFICATION				5. TYPE	
UNIT	MAKE	MODEL	SERIAL NO.	REPAIR	ALTERATION
AIRFRAME	***** (As described in item 1 above) *****				X
POWERPLANT					
PROPELLER					
APPLIANCE	TYPE				
	MANUFACTURER				

6. CONFORMITY STATEMENT		
A. AGENCY'S NAME AND ADDRESS	B. KIND OF AGENCY	C. CERTIFICATE NO.
Michael C. Lloyd Box 5155 Kingsport, TN 37663	<input checked="" type="checkbox"/> U.S. CERTIFICATED MECHANIC	415869827
	<input type="checkbox"/> FOREIGN CERTIFICATED MECHANIC	
	<input type="checkbox"/> CERTIFICATED REPAIR STATION	
	<input type="checkbox"/> MANUFACTURER	

D. I certify that the repair and/or alteration made to the unit(s) identified in item 4 above and described on the reverse or attachments hereto have been made in accordance with the requirements of Part 43 of the U.S. Federal Aviation Regulations and that the information furnished herein is true and correct to the best of my knowledge.

DATE 6/1/88	SIGNATURE OF AUTHORIZED INDIVIDUAL <i>Michael C. Lloyd</i>
----------------	---

7. APPROVAL FOR RETURN TO SERVICE

Pursuant to the authority given persons specified below, the unit identified in item 4 was inspected in the manner prescribed by the Administrator of the Federal Aviation Administration and is APPROVED REJECTED

BY	FAA PLT. STANDARDS INSPECTOR	MANUFACTURER	<input checked="" type="checkbox"/> INSPECTION AUTHORIZATION	OTHER (Specify)
	FAA DESIGNEE	REPAIR STATION	CANADIAN DEPARTMENT OF TRANSPORT INSPECTOR OF AIRCRAFT	
DATE OF APPROVAL OR REJECTION 6/1/88	CERTIFICATE OR DESIGNATION NO. 415869827	SIGNATURE OF AUTHORIZED INDIVIDUAL <i>Michael C. Lloyd</i>		

NOTICE
Weight and balance or operating limitation changes shall be entered in the appropriate aircraft record. An alteration must be compatible with all previous alterations to assure continued conformity with the applicable airworthiness requirements.

8. DESCRIPTION OF WORK ACCOMPLISHED (if more space is required, attach additional sheets. Identify with aircraft nationality and registration mark and date work completed.)

Removed standard brake disc, left and right.
Installed stainless disc per instruction, STC SA174550.
Weight and balance/equipment list revised and log book entry made.
All workmanship accomplished per AC4313, 1A and 2A.

_____ END _____

Michael C. Lloyd
Michael C. Lloyd
IA415869827

6/1/88

ADDITIONAL SHEETS ARE ATTACHED

MAJOR REPAIR AND ALTERATION
(Airframe, Powerplant, Propeller, or Appliance)

FOR FAA USE ONLY
OFFICE IDENTIFICATION

INSTRUCTIONS: Print or type all entries. See FAR 43.9, FAR 43 Appendix B, and AC 43.9-1 (or subsequent revision thereof) for instructions and disposition of this form.

1. AIRCRAFT	MAKE Piper	MODEL PA28-151
	SERIAL NO. 28-7415398	NATIONALITY AND REGISTRATION MARK N42671
2. OWNER	NAME (As shown on registration certificate) Piper Aircraft Corporation	ADDRESS (As shown on registration certificate) P.O. Box 1328 Vero Beach, Florida 32960

3. FOR FAA USE ONLY

4. UNIT IDENTIFICATION				5. TYPE	
UNIT	MAKE	MODEL	SERIAL NO.	REPAIR	ALTERATION
AIRFRAME	***** (As described in item 1 above) *****				X
POWERPLANT					
PROPELLER					
APPLIANCE	TYPE				
	MANUFACTURER				

6. CONFORMITY STATEMENT

A. AGENCY'S NAME AND ADDRESS Piper Aircraft Corporation P.O. Box 1328 Vero Beach, Florida 32960	B. KIND OF AGENCY	C. CERTIFICATE NO. FAA DOA SO-1
	<input type="checkbox"/> U.S. CERTIFICATED MECHANIC	
	<input type="checkbox"/> FOREIGN CERTIFICATED MECHANIC	
	<input checked="" type="checkbox"/> CERTIFICATED REPAIR STATION	
	<input checked="" type="checkbox"/> MANUFACTURER	

I certify that the repair and/or alteration made to the unit(s) identified in item 4 above and described on the reverse or attachments hereto have been made in accordance with the requirements of Part 43 of the U.S. Federal Aviation Regulations and that the information furnished herein is true and correct to the best of my knowledge.

DATE APR 8 1974	SIGNATURE OF AUTHORIZED INDIVIDUAL <i>Anthony P. Duvola</i>
--------------------	--

7. APPROVAL FOR RETURN TO SERVICE

Pursuant to the authority given persons specified below, the unit identified in item 4 was inspected in the manner prescribed by the Administrator of the Federal Aviation Administration and is APPROVED REJECTED

FAA FLT. STANDARDS INSPECTOR	<input checked="" type="checkbox"/> MANUFACTURER	INSPECTION AUTHORIZATION	OTHER (Specify)
FAA DESIGNEE	REPAIR STATION	CANADIAN DEPARTMENT OF TRANSPORT INSPECTOR OF AIRCRAFT	
DATE OF APPROVAL OR REJECTION APR 8 1974	CERTIFICATE OR DESIGNATION NO. DOA SO-1	SIGNATURE OF AUTHORIZED INDIVIDUAL <i>A.W. Garbous</i>	

Weight and balance or operating limitation changes shall be entered in the appropriate aircraft record. An alteration must be compatible with all previous alterations to assure continued conformity with the applicable airworthiness requirements.

NOTICE

8. DESCRIPTION OF WORK ACCOMPLISHED (if more space is required, attach additional sheets. Identify with aircraft nationality and registration mark and date work completed.)

Installed ALCON Model 225 Mixture Control Indicator per the manufacturer's instructions and Lycoming Service Instruction #1094B.

1. Gauge is mounted in the lower sub-panel (factory provided) instrument hole in the pilot's view.

2. Probe is mounted in #4 cylinder.

3. Lead wire is routed with existing harness.

4. Aircraft Equipment List and Weight and Balance are revised.

5. Aircraft flown for function check.

-END-

ADDITIONAL SHEETS ARE ATTACHED

EQUIPMENT LIST

The following is a list of equipment which may be installed in the PA-28-151. Items marked with an "X" are items installed when the airplane was delivered by the manufacturer.

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
A. Propeller and Propeller Accessories					
<u>X</u>	Propeller, Sensenich 74DM6-0-58	31.6	3.8	120	TC P886
	or McCauley 1C1 60EGM7653	30.6	3.8	116	TC P910
<u>X</u>	Spinner and Attachment Plates	2.5	3.0	7	TC 2A13

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
B. Engine and Engine Accessories					
<u>X</u>	Engine - Lycoming Model O-320-E3D	268.0	21.2	5682	TC 274
<u>X</u>	Fuel Pump, Electric Auxiliary, Bendix Model 478360	1.6	44.7	72	TC 2A13
<u>X</u>	Fuel Pump, Engine Driven, Lycoming Dwg. No. 73297, 74082, 75148 or 75246	1.7	36.3	62	TC P286
<u>X</u>	Oil Cooler, Piper Dwg. 18622 Harrison *C-8526250	1.9	31.3	58	TC 2A13
<u>X</u>	Air Filter, Piper Dwg. 35477	.4	30.0	12	TC 2A13
<u>X</u>	Alternator, 60 Amp, Prestolite No. ALY6408	10.5	14.0	147	TC 2A13
<u>X</u>	Starter - Lycoming 76210 (Prestolite MZ4204)	* 17.0	14.5	246	TC 274

*Included in Engine Weight.

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
C. Landing Gear and Brakes					
<u>X</u>	Two Main Wheel Assemblies	32.3	109.6	3540	TC 2A13
	(a) Cleveland Aircraft Products Wheel Assembly No. 40-86 Brake Assembly No. 30-55 STC SA174550				
	(b) Two Main 4-Ply Rating Tires 6.00 - 6 with Regular Tubes				
<u>X</u>	One Nose Wheel 5.00 - 5	8.3	29.8	247	TC 2A13
	(a) Cleveland Aircraft Products Wheel Assembly No. 40-77A (Less Brake Drum)				
	(b) One Nose Wheel 4-Ply Rating Tire 5.00 - 5 with Regular Tube				

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
D. Electrical Equipment					
<u>X</u>	Stall Warning Device, Safe Flight Instrument Corporation No. 53514-101	.4	80.2	32	TSO C30b
<u>X</u>	Voltage Regulator, Wico Electric *X-16300B	.5	51.9	26	TC 2A13
	Battery 12V, 25 A.H., Rebat Model S-25	21.5	168.0	3612	TC 2A13
<u>X</u>	Overvoltage Relay, Wico Electric No. X16799	.5	55.4	28	TC 2A13

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
E. Instrument					
✕	Compass - Piper Dwg. 67462	.9	59.9	54	TSO C7c
	Airspeed Indicator, Piper Dwg. 63205-2	.6	61.8	37	TSO C2b
✕	Tachometer, Piper Dwg. 62177-3	.7	61.2	43	TC 2A13
✕	Altimeter, Piper PS50008-2 or -3	1.0	60.9	61	TSO C10b
✕	Engine Cluster, Piper Dwg. 95241-7	.8	62.4	50	TC 2A13
✕	Ammeter - Piper Dwg. 66696	.3	62.4	19	TC 2A13

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
F. Miscellaneous					
<u>X</u>	Forward Seat Belts (2) .75 lbs. each Piper Spec. PS50039-4-2A	1.5	81.9	123	TSO C22
<u>X</u>	Inertia Safety Belts (2) 0.9 lbs. each Piper Spec. PS50039-4-9	1.8	119.6	215	TC 2A13
<u>X</u>	Rear Seat Belts (2) .70 lbs. each Piper Spec. PS50039-4-3	1.4	123.0	172	TSO C22
<u>X</u>	Rear Seat	20.0	124.2	2484	TC2A13
<u>X</u>	Flight Manual	2.6	—	—	TC 2A13
<u>X</u>	Toe Brakes (Dual) Piper Dwg. 63473	10.5	49.6	521	TC 2A13

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
	G. Engine and Engine Accessories (Optional Equipment)				
<u>X</u>	Vacuum Pump, Airborne Mfg. Co., Model No. 200cc and Drive	5.0	32.0	160	TC 2A13
<u>X</u>	Oil Filter - Lycoming No. 75528 (AC * OF5578770)	3.3	35.5	117	TC 2A13
<u>X</u>	Vacuum Regulator	.7	52.0	36	TC 2A13
<u>X</u>	Vacuum Filter	.3	52.0	16	TC 2A13
<u>X</u>	Primer System, Piper Dwg. 35327-0	1.2	50.0	60	TC 2A13
	Starter - Lycoming 76211 (Prestolite MZ4206) (Weight 18 lbs)	* 1.0	14.5	15	TC 286
	Vacuum Pump, Airborne Mfg. Co., Model 211cc and Drive, PAC 79399-0	3.2	32.0	103	TC 2A13

*Weight and moment difference between standard and optional equipment.

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
	H. Electrical Equipment (Optional Equipment)				
_____	Rotating Beacon, Grimes *40-0101-15-12	1.5	263.4	395	TC 2A13
_____	✕ Landing Light, G.E. Model 4509	.5	13.1	7	TC 2A13
_____	✕ Navigation Lights (2) Grimes Model A1285 (Red and Green)	.4	106.6	43	TSO C30b
_____	✕ Navigation Light (Rear) (1) Grimes Model 2064 (White)	.2	281.0	56	TSO C30b
_____	✕ Battery 12V, 35 A.H. Rebat R-35 (Weight 27.0 lbs.)	* 5.5	168.0	924	TC 2A13
_____	✕ Cabin Light, Piper Dwgs. 66632-0 & 95229-0	.3	99.0	30	TC 2A13
_____	✕ Cabin Speaker SB-15052 or 6EU 1937	.8	99.0	79	TC 2A13
_____	✕ Auxiliary Power Receptacle, Piper Dwg. 35289	2.7	178.5	482	TC 2A13
_____	✕ External Power Cable 62355-11	4.6	142.8	657	TC 2A13
_____	✕ Piper Pitch Trim, Piper Dwg. 67498-0	4.3	155.3	668	TC 2A13
_____	✕ Heated Pitot Head Piper Dwg. 35493-2	.4	100.0	40	TC 2A13

*Weight and moment difference between standard and optional equipment.

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
H. Electrical Equipment (Optional Equipment) (cont)					
Red Strobe Light, Whelen Engineering Co. Piper Dwg. 99033-7					
_____	Power Supply, Whelen Model HS A412A-14	2.3	198.0	455	TC 2A13
_____	Light (Fin Tip)	.4	263.4	105	TC 2A13
_____	Cable	.4	230.7	92	TC 2A13
Red/White Strobe Light, Whelen Engineering Co. Piper Dwg. 99033-10					
<u> X </u>	Power Supply, Whelen Model HD, T3 No. A413 (with Fin and Wing Lights)	3.0	198.0	594	TC 2A13
<u> X </u>	Light (Fin Tip)	.4	263.4	105	TC 2A13
<u> X </u>	Cable	.4	230.7	92	TC 2A13
<u> X </u>	Lights (Wing Tip) (2)	.3	106.6	32	TC 2A13
<u> X </u>	Cables	2.0	115.6	231	TC 2A13

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
1. Instruments (Optional Equipment)					
<u> </u> X	Suction Gauge, Piper Dwg. 99480-0 or -2	.5	62.2	31	TC 2A13
<u> </u> X	Vertical Speed, Piper Dwg. 99010-2, -4 or -5	1.0	60.9	61	TSO C8b
<u> </u>	Attitude Gyro, Piper Dwg. 99002-2, -3, -4 or -5	2.2	59.4	131	TSO C4c
<u> </u>	Directional Gyro, Piper Dwg. 99003-2, -3, -4 or -5	2.6	59.7	155	TSO C5c
<u> </u> X	Air Temperature Gauge, Piper Dwg. 99479-0 or -2	.2	72.6	15	TC 2A13
<u> </u> X	Clock, Piper Dwg. 99478	.4	62.4	25	TC 2A13
<u> </u> X	Tru-Speed Indicator, Piper Dwg. 62143 or -12	(Same as Standard Equipment)			TC 2A13
<u> </u> X	Turn and Slip Indicator, Piper PS50030-2 or -3	2.6	59.7	155	TSO C3b
<u> </u> X	Exhaust gas temperature guage	.7	55.4	39	

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
J. Autopilots (Optional Equipment)					
AutoControl III, Piper Dwg. 79221-7,-8,-9					
<u>X</u>	Roll Servo, *1C363-1-430R	2.5	122.2	306	STC SA1406SW
<u>X</u>	Console, *1C338E	1.2	60.1	72	STC SA1406SW
<u>X</u>	Cables	.7	95.5	67	STC SA1406SW
<u>X</u>	Attitude Gyro, *52D66	2.3	59.4	137	STC SA1406SW
<u>X</u>	Directional Gyro, *52D54	3.2	59.0	189	STC SA1406SW
<u>X</u>	Omni Coupler, *1C388	.9	59.3	53	STC SA1406SW
AutoFlite II, Piper Dwg. 99447-3					
<u> </u>	Roll Servo, *1C363-1-430R	2.5	122.2	306	STC SA1406SW
<u> </u>	Cable	.7	93.4	65	STC SA1406SW
<u> </u>	Panel Unit, *52D75-3 or -4	2.4	59.4	143	STC SA1406SW

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
K. Radio Equipment (Optional Equipment)					
_____	Narco Mark 16 (VHF Comm/Nav) Transceiver, Single	7.5	56.9	427	TC 2A13
_____	Transceiver, Dual	15.0	56.9	854	TC 2A13
_____	Narco VOA-50M Omni Converter	2.1	59.9	126	TC 2A13
_____	Narco VOA-40 (M) Omni Converter	1.9	59.9	114	TC 2A13
_____	Narco VOA-40 Omni Converter	1.9	59.9	114	TC 2A13
_____	Narco Comm 10A VHF Transceiver	3.9	57.4	224	TC 2A13
_____	Narco Comm 11A VHF Transceiver	3.6	57.4	207	TC 2A13
_____	Narco Dual Comm 11A VHF Transceiver	7.1	57.4	408	TC 2A13
_____	Narco Nav 10 VHF Receiver	1.9	58.6	111	TC 2A13
_____	Narco Nav 11 VHF Receiver	2.8	58.6	164	TC 2A13
_____	Narco Nav 12 VHF Receiver	3.4	58.6	199	TC 2A13
_____	Narco Dual Nav 11 VHF Receiver	5.6	58.6	328	TC 2A13
_____	King KX-175B VHF Transceiver	9.4	56.6	532	TC 2A13
_____	King KN-73 Glide Slope Receiver	3.2	184.3	590	TC 2A13
_____	King KN-77 VOR/LOC Converter	3.6	183.6	661	TC 2A13
_____	King KNI-520 VOR/ILS Indicator	1.7	60.5	103	TC 2A13
_____	King KX-175B VHF Transceiver (2nd)	8.6	56.6	487	TC 2A13
_____	King KN-77 VOR/LOC Converter	4.2	183.6	771	TC 2A13
_____	King KNI-520 VOR/ILS Indicator	1.7	60.5	103	TC 2A13

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
K. Radio Equipment (Optional Equipment) (cont)					
_____	Narco Comm 110 VHF Transceiver	3.0	57.4	172	TC 2A13
_____	Narco Comm 111 Transceiver	3.0	57.4	172	TC 2A13
_____	Narco Dual Comm 111 Transceiver	6.0	57.4	344	TC 2A13
_____	Narco Nav 110 VHF Receiver	1.7	58.6	100	TC 2A13
_____	Narco Nav 111 VHF Receiver	2.5	58.6	147	TC 2A13
_____	Narco Nav 112 VHF Receiver	3.3	58.6	193	TC 2A13
	King KX170B () (VHF Comm/Nav)				
_____	Transceiver, Single	7.5	56.6	425	TC 2A13
X	Transceiver, Dual	15.0	56.6	849	TC 2A13
X	King KI201 () VOR/LOC Ind.	2.5	59.6	149	TC 2A13
_____	King Dual KI201 () VOR/LOC Ind.	5.0	59.9	300	TC 2A13
X	King KI214 () VOR/LOC/GS Ind.	3.3	59.9	198	TC 2A13
X	Nav Receiving Antenna	.5	265.0	133	TC 2A13
X	Cable, Nav Antenna	.9	157.0	141	TC 2A13
_____	*1 VHF Comm Antenna	.3	157.8	47	TC 2A13
_____	Cable, Antenna *1 VHF	.4	103.4	41	TC 2A13
_____	*2 VHF Comm Antenna	.3	192.8	58	TC 2A13
_____	Cable, Antenna* 2 VHF	.5	120.9	60	TC 2A13

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
K. Radio Equipment (Optional Equipment) (cont)					
	Anti Static Kit				
<u>X</u>	*1 VHF Comm Antenna	1.0	160.8	161	TC 2A13
<u>X</u>	Cable *1 VHF Antenna	0.4	103.4	41	TC 2A13
<u>X</u>	*2 VHF Comm Antenna	1.0	195.8	196	TC 2A13
<u>X</u>	Cable *2 VHF Comm Antenna	0.5	120.9	60	TC 2A13
<u>X</u>	Low Frequency Antenna	0.5	147.5	74	TC 2A13
<u>X</u>	Static Wicks	—	—	—	TC 2A13
	Narco ADF-31 A/B				
_____	Panel Unit	5.0	58.5	293	TC 2A13
_____	Sensor Unit	2.5	162.7	407	TC 2A13
_____	Sensor Cable	2.3	100.6	231	TC 2A13
_____	Sense Antenna and Cable	.4	150.0	60	TC 2A13
	Bendix ADF-T-12C or Bendix ADF-T-12D				
_____	Receiver	3.5	59.4	208	TC 2A13
_____	Audio Amplifier	.8	52.4	42	TC 2A13
_____	Servo Indicator	1.7	60.9	104	TC 2A13
_____	Loop Antenna	1.3	160.8	209	TC 2A13
_____	Cable, Interconnecting	2.3	108.0	248	TC 2A13
_____	Sense Antenna and Cable	.4	150.0	60	TC 2A13
	King KR-85				
<u>X</u>	Receiver	4.3	59.4	255	TC 2A13
<u>X</u>	Servo Indicator	1.2	61.3	74	TC 2A13
<u>X</u>	Loop Antenna	1.3	161.5	210	TC 2A13
<u>X</u>	Loop Cable	1.8	108.0	194	TC 2A13
_____	Audio Amplifier	.8	51.0	41	TC 2A13
<u>X</u>	Sense Antenna and Cable	.4	150.0	60	TC 2A13
	PM-1 Marker Beacon				
_____	Receiver	1.1	121.3	133	TC 2A13
_____	Remote Unit	.3	128.4	39	TC 2A13
_____	Cable	.3	80.0	24	TC 2A13
	UGR-2 Glide Slope				
_____	Receiver	2.4	173.8	417	TC 2A13
_____	Cable	1.8	128.0	230	TC 2A13
<u>X</u>	Antenna	.4	87.4	35	TC 2A13
<u>X</u>	Cable, Antenna	.5	145.0	73	TC 2A13

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
K. Radio Equipment (Optional Equipment) (cont)					
_____	Narco CP-25B/125 Audio Selector Panel	1.5	60.2	90	TC 2A13
_____	Narco MBT-12A Marker Beacon Panel	1.2	52.5	63	TC 2A13
_____	Narco AT50A Transponder Panel Unit	* 3.0	57.3	172	TC 2A13
_____	King KT 76 78 Transponder Panel Unit	3.1	58.1	180	TC 2A13
_____	Antenna and Cable	—	—	—	TC 2A13
_____	King KMA-20 Audio Panel	2.8	60.2	169	TC 2A13
_____	Antenna	.5	116.3	58	TC 2A13
_____	Cable	.4	87.5	35	TC 2A13
_____	King KN60C DME Receiver	6.8	56.7	386	TC 2A13
_____	Antenna	.2	107.1	21	TC 2A13
_____	Cable, Antenna	0.3	80.6	24	TC 2A13
_____	Piper Automatic Locator, Piper Dwg. 99890 Transmitter	1.7	236.2	402	TC 2A13
_____	Antenna and Cable	.2	224.4	45	TC 2A13
_____	Shelf and Access Plate	.3	235.4	71	TC 2A13
_____	Audio Selector Panel, Piper Dwg. 99395-0, -2 or -3	.7	61.3	43	TC 2A13
_____	Microphone (Dynamic) Piper Dwg. 68856-12	.5	70.0	35	TC 2A13
_____	Microphone (Carbon), Piper Dwg. 68856-10	.5	70.0	35	TC 2A13
_____	Headset, Piper Dwg. 68856-10	.5	60.0	30	TC 2A13

*Weight includes Antenna and Cable.

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
	L. Miscellaneous (Optional Equipment)				
_____	Fire Extinguisher, Scott Aviation 42211-00, Piper Dwg. 76167-2	5.3	71.0	376	TC 2A13
<u> X </u>	Assist Step Piper Dwg. 65384-0	1.8	156.0	281	TC 2A13
<u> X </u>	Inertia Safety Belts (Rear) (2) 0.8 lbs. each Piper Spec. PS50039-4-6	1.6	140.3	224	TC 2A13
<u> X </u>	Tow Bar, Piper Dwg. 99458	1.3	140.0	182	TC 2A13
<u> X </u>	Nose Wheel Fairing Piper Dwg. 35513	3.8	29.8	113	TC 2A13
<u> X </u>	Main Wheel Fairings Piper Dwg. 65237	7.6 7.6	113.6 109.6	863 767	TC 2A13
<u> X </u>	Vert. Adj. Front Seats (Left) Piper Dwg. 76340-0	6.6 * 8.8	80.7 88.8	533 780	TC 2A13
_____	Vert. Adj. Front Seat (Right) Piper Dwg. 76340-1	* 3.2	85.7	280	TC 2A13
<u> X </u>	Super Cabin Sound Proofing Piper Dwg. 79030-2	18.1	86.8	1571	TC 2A13
<u> X </u>	Rear Seat Vents	2.5	98	245	TC 2A13
<u> X </u>	Baggage Tie Down Straps	1.3	126.7	165	TC 2A13
<u> X </u>	Lighter, 12V Universal 200462	.2	62.9	13	TC 2A13
<u> X </u>	Assist Strap and Coat Hook, Piper Dwg. 62353-5	.2	109.5	22	TC 2A13

*Weight and moment difference between standard and optional equipment.

CHEROKEE WARRIOR

Item	Item	Weight Lbs.	Arm Aft Datum	Moment	Cert. Basis
L. Miscellaneous (Optional Equipment) (cont)					
<u> </u>	<input checked="" type="checkbox"/> Overhead Vent System with Ground Ventilating Blower, Piper Dwg. 76304-2	12.9	170.1	2194	TC 2A13
<u> </u>	Overhead Vent System, Piper Dwg. 76304-0	5.3	155.8	822	TC 2A13
<u> </u>	Alternate Static Source, Piper Dwg. 67479-2	.4	61.0	24	TC 2A13
Calibrated Alternate Static Source					
Placard Required: Yes <u> </u> No <u> </u>					
<u> </u>	<input checked="" type="checkbox"/> Headrest (2) (Front)	2.2	94.5	208	TC 2A13
<u> </u>	<input checked="" type="checkbox"/> Sun Visors, Piper Dwg. 66991-0	1.5	85.0	128	TC 2A13
<u> </u>	Zinc Chromate Finish, Piper Dwg. 65665	5.0	158.0	790	TC 2A13
	X Service Kit 764-3030	2.0	113.6	227	
	X STC SA174550	4.0	109.6	438.4	
TOTAL OPTIONAL EQUIPMENT		<u>159.1</u>	<u>101.7</u>	<u>16175</u>	

EXTERIOR FINISH

Base Color Juneau White

Registration No. Color Red

Trim Color Ocala Orange

Type Finish Lacquer


Accent Color Dakota Black

THIS PAGE INTENTIONALLY LEFT BLANK

LOADING INSTRUCTIONS

LOADING INSTRUCTIONS

**THIS SECTION IS NOT
APPLICABLE TO THIS AIRPLANE**



OPERATING INSTRUCTIONS

Preflight	7-1
Walk-Around Inspection	7-1
Starting Engine	7-2
Starting Engine When Cold	7-3
Starting Engine When Hot	7-3
Starting Engine When Flooded	7-3
Starting Engine with External Power Source	7-3
Warm-Up	7-4
Ground Check	7-4
Takeoff	7-5
Climb	7-6
Stalls	7-6
Cruising	7-6
Turbulent Air Operation	7-7
Maneuvers	7-7
Engine Power Loss	7-8
Approach and Landing	7-8
Stopping Engine	7-9
Airspeed Data	7-9
Mooring	7-9
Weight and Balance	7-9
Emergency Locator Transmitter	7-10


OPERATING INSTRUCTIONS

PREFLIGHT

The airplane should be given a thorough preflight and walk-around inspection. The preflight should include a check of the airplane's operational status and computation of weight and C.G. limits, takeoff distance, and in flight performance. A weather briefing should be obtained for the intended flight path, and any other factors relating to a safe flight should be checked before takeoff.

WALK-AROUND INSPECTION

1. In Cabin
 - a. Release seat belt securing controls.
 - b. Master switch ON.
 - c. Check fuel quantity gauges.
 - d. Master switch OFF.



CHEROKEE WARRIOR

2. Control Surfaces
 - a. Check for external damage and operational interference of control surfaces or hinges.
 - b. Insure that wings and control surfaces are free of snow, ice, or frost.
3. Wings
 - a. Visually check fuel supply; secure caps.
 - b. Drain fuel sumps (2 on each wing).
 - c. Check that fuel system vents are open.
 - d. On left wing check that pitot head cover is removed and that holes in the pitot-static head are unobstructed.
4. Main Landing Gear
 - a. Check main gear shock struts for proper inflation (approximately 4.50 inches showing).
 - b. Check tires for cuts, wear and proper inflation.
 - c. Check brake blocks and discs for wear and damage.
5. Nose Section
 - a. Inspect windshield for cleanliness.
 - b. Check the propeller and spinner for defects, dirt and cracks.
 - c. Check for obvious fuel and oil leaks.
 - d. Drain gascolator fuel sump (left side of airplane).
 - e. Check oil level, 8 quarts maximum. (Insure that the dipstick is properly seated.)
 - f. Check cowling and inspection covers for security.
 - g. Check nose wheel tire for damage, wear, and proper inflation.
 - h. Check nose gear shock strut for proper inflation (approximately 3.25 inches showing).
 - i. Check for foreign matter in air inlets.
6. Fuselage
 - a. Stow tow bar if used.
 - b. Check baggage for proper storage and security.
 - c. Close and secure the baggage compartment door.
7. Inside Airplane
 - a. Upon entering the airplane, ascertain that all flight controls operate properly.
 - b. Close and secure the cabin door.
 - c. Check that required papers are in the airplane.
 - d. Fasten seat belts and shoulder harnesses. Check function of inertia reels.

STARTING ENGINE

1. Set parking brake ON.
2. Set the carburetor heat control in the full OFF position.
3. Select the desired tank with the fuel selector valve.

STARTING ENGINE WHEN COLD

1. Open throttle approximately 1/4 inch.
2. Turn the master switch ON.
3. Turn the electric fuel pump ON.
4. Move the mixture control to FULL RICH.
5. Engage the starter by rotating the magneto switch clockwise and pressing in.
6. When the engine fires, advance the throttle to the desired setting. If the engine does not fire within five to ten seconds, disengage the starter and prime with one to three strokes of the priming pump if one is installed. Repeat the starting procedure.

STARTING ENGINE WHEN HOT

1. Open the throttle approximately 1/2 inch.
2. Turn the master switch ON.
3. Turn the electric fuel pump ON.
4. Put the mixture control in IDLE CUT-OFF.
5. Engage the starter by rotating the magneto switch clockwise and pressing in. When the engine fires, advance the mixture control and move the throttle to the desired setting.

STARTING ENGINE WHEN FLOODED

1. Open the throttle FULL.
2. Turn the master switch ON.
3. Turn the electric fuel pump OFF.
4. Put the mixture control in IDLE CUT-OFF.
5. Engage the starter by rotating the magneto switch clockwise and pressing in. When the engine fires, advance the mixture control and retard the throttle.

When the engine is firing evenly, advance the throttle to 800 RPM. If oil pressure is not indicated within 30 seconds, stop the engine and determine the trouble. In cold weather it will take a few seconds longer to get an oil pressure indication. If the engine has failed to start, refer to the "Lycoming Operating Handbook" for the appropriate engine model.

Starter manufacturers recommend that cranking periods be limited to thirty seconds with a two minute rest between cranking periods. Longer cranking will shorten the life of the starter.

STARTING ENGINE WITH EXTERNAL POWER SOURCE*

An optional feature called Piper External Power (PEP) allows the operator to use an external battery to crank the engine without having to gain access to the airplane battery.

The procedure is as follows:

1. Turn the airplane master switch OFF.

*Optional equipment

CHEROKEE WARRIOR

2. Connect the RED lead of the PEP kit jumper cable to the POSITIVE (+) terminal of an external 12-volt battery and the BLACK lead to the NEGATIVE (-) terminal.
3. Insert the plug of the jumper cable into the socket located on the airplane's fuselage.
4. Turn the airplane master switch ON and proceed with the normal engine starting technique.
5. After the engine has been started, turn the master switch OFF and disconnect the jumper cable plug from the airplane.
6. Turn the master switch ON and check the alternator ammeter for indication of output. DO NOT ATTEMPT FLIGHT IF THERE IS NO INDICATION OF ALTERNATOR OUTPUT.

WARM-UP

Warm-up the engine at 800 to 1200 RPM for not more than two minutes in warm weather or four minutes in cold weather. Avoid prolonged idling at low RPM as this practice may result in fouled spark plugs. If necessary to hold before takeoff, it is recommended that the engine be idled at 1200 RPM.

Takeoff may be made as soon as the ground check is completed, provided the throttle may be opened fully without backfiring or skipping and without a reduction in engine oil pressure.

GROUND CHECK

Check the magnetos at 2000 RPM by switching from BOTH to RIGHT, then back to BOTH before switching to LEFT. The drop on either magneto should not exceed 175 RPM, and each magneto should read within 50 RPM of the other. Prolonged operation on one magneto should be avoided.

Check the vacuum gauge; the indicator should read $5'' \pm .1''$ Hg at 2000 RPM.

Check both the oil temperature and pressure. The temperature may be low for some time if the engine is being run for the first time of the day, but as long as the oil pressure is within limits, the engine is ready for takeoff.

Carburetor heat should also be checked prior to takeoff to be sure that the control is operating properly and to clear any ice that may have formed during taxiing. Avoid prolonged operation with carburetor heat ON as the air is unfiltered. Be sure that carburetor heat is OFF for takeoff.

Operation of the engine driven fuel pump should be checked while taxiing or during preflight engine runup by switching the electric fuel pump OFF and observing the fuel pressure gauge. The electric fuel pump should be ON during takeoff to prevent loss of power during takeoff should the engine driven pump fail. The engine is warm enough for takeoff when the throttle can be fully opened without the engine faltering.

TAKEOFF

Just before takeoff the following items should be checked:

1. Fuel - on proper tank
2. Electric fuel pump - on
3. Engine gauges - checked
4. Flaps - set
5. Carburetor heat - off
6. Mixture - set
7. Seat backs - erect
8. Safety belts/harness - fastened
9. Trim tab - set
10. Controls - free
11. Door - latched

The takeoff technique is conventional. The trim tab should be set slightly aft of neutral with the exact setting determined by the loading of the airplane. Allow the airplane to accelerate to 50 to 60 miles per hour, then ease back on the wheel enough to let the airplane fly itself from the ground. Premature raising of the nose or raising it to an excessive angle will result in a delayed takeoff. After takeoff, let the airplane accelerate to the desired climb speed by lowering the nose slightly.

Takeoffs are normally made with flaps up; however, for short field takeoffs and for takeoffs under difficult conditions such as deep grass or a soft surface, distances can be reduced appreciably by lowering the flaps to 25° and rotating at lower airspeeds.

Short Field, Obstacle Clearance:

Lower the flaps to 25° . Apply full power before brake release. Accelerate to 66 MPH CAS and rotate, maintaining 66 MPH CAS until obstacle clearance has been attained. After the obstacle has been cleared accelerate to 87 miles per hour and then slowly retract the flaps.

Short Field, No Obstacle:

Use of partial flaps does not decrease minimum ground roll, therefore, leave the flaps up or lower the flaps to 25° as desired. Apply full power before brake release. Accelerate to 65 MPH CAS with flaps up or 52 MPH CAS with flaps at 25° and rotate. After breaking ground, accelerate to best rate of climb speed of 87 MPH CAS. Slowly retract the flaps while climbing out.

Soft Field, Obstacle Clearance:

Lower the flaps to 25° . Accelerate airplane, lift nose gear off as soon as possible, and lift off at lowest possible airspeed. Accelerate just above the ground to 66 MPH CAS to climb past obstacle clearance height. Continue climbing while accelerating to the best rate of climb speed, 87 miles per hour, and slowly retract the flaps.

Soft Field, No Obstacle:

Lower the flaps to 25° . Accelerate the airplane and lift the nose gear off as soon as possible, then lift off at the lowest possible airspeed. Accelerate just above the ground to the best rate of climb speed, 87 miles per hour. Climb out while slowly retracting the flaps.

CHEROKEE WARRIOR

CLIMB

The best rate of climb at gross weight will be obtained at 87 miles per hour. The best angle of climb is at 76 miles per hour. At lighter than gross weight, these speeds are somewhat reduced. For climbing en route, a speed of 100 miles per hour is recommended. This will produce better forward speed and increased visibility over the nose during the climb. Shallow turns of a few degrees will also aid forward visibility during climb out.

STALLS

Stall characteristics are conventional. Audible stall warning is provided by a horn located behind the instrument panel which sounds automatically at between 5 and 10 miles per hour above stall speed.

Stall speed at a gross weight of 2325 pounds with power off and full flaps is 58 miles per hour. With flaps up, this speed is increased.

The stall speed chart is at gross weight. Stall speeds at lower weights will be correspondingly less.

STALL SPEED TABLE

Angle of Bank	Flaps 40°	Flaps Retracted
0°	58 MPH	64.5 MPH
20°	60 MPH	67 MPH
40°	66 MPH	74 MPH
50°	72 MPH	80 MPH
60°	82 MPH	91 MPH

Power Off – Gross Weight 2325 Lbs.

CRUISING

The cruising speed is determined by many factors, including power setting, attitude, temperature, loading, and equipment installed on the airplane.

The normal cruising power is 75% of the rated horsepower of the engine. True airspeeds, which may be obtained at various altitudes and power settings, can be determined from the charts in the Performance Charts Section of this manual.

Use of the mixture control in cruising flight reduces fuel consumption significantly, especially at higher altitudes.

The mixture should be leaned at the pilot's discretion when 75% power or less is being used. If any doubt exists as to the amount of power being used, the mixture should be in the FULL RICH position for all operations.

To lean the mixture, pull the mixture control until the engine becomes rough, indicating that the lean mixture limit has been reached in the leaner cylinders. Then enrich the mixture by pushing the control toward the instrument panel until engine operation becomes smooth.

The continuous use of carburetor heat during cruising flight decreases engine efficiency. Unless icing conditions in the carburetor are severe, do not cruise with carburetor heat on. Apply FULL carburetor heat slowly and only for a few seconds at intervals determined by the icing conditions.

In order to keep the airplane in best lateral trim during cruise flight, the fuel should be used alternately from each tank. It is recommended that one tank be used for one hour after takeoff, the other tank be used for two hours, then return to the first tank. The second tank will contain approximately one half hour of fuel. Do not run tanks completely dry in flight.

The following is a list of some fuel management recommendations:

1. Fuel quantity should be visually checked in both tanks before entering the airplane.
2. Takeoff should be made on the fuller tank to assure best fuel flow, and this tank selected before or immediately after starting to establish an adequate fuel flow before takeoff. The tank with the higher fuel quantity should be selected for landing.
3. Fuel tank selection at low altitude is not recommended since adequate recovery time is essential in the event of an error in fuel selection.
4. The electric fuel pump should be turned on before switching tanks and left on for a short period thereafter.
5. To avoid the necessity of making a hasty selection and to assure a continuous fuel flow, the selector should be changed to another tank before the fuel is exhausted from the tank in use.
6. Operation of the engine driven pump should be checked while taxiing or during the preflight runup by switching off the electric fuel pump and observing the fuel pressure.
7. During cruise, the electric fuel pump should be in the off position so that any malfunction of the engine driven fuel pump is immediately apparent.
8. If signs of fuel starvation should occur at any time during flight, fuel exhaustion should be suspected, at which time the fuel selector should immediately be positioned to the fuller tank and the electric fuel pump switched to the on position.

TURBULENT AIR OPERATION

In keeping with good operating practice used in all aircraft, it is recommended that when turbulent air is encountered or expected, the airspeed be reduced to maneuvering speed to reduce the structural load caused by gusts and to allow for inadvertent speed build-ups which may occur as a result of the turbulence or distractions caused by the conditions.

MANEUVERS

The airplane must be operated as a normal or utility category airplane in compliance with the operating limitations stated in the form of placards, markings, and manuals. No acrobatic maneuvers are approved for normal category operations. Spins are prohibited for both normal and utility category operations.

CHEROKEE WARRIOR

ENGINE POWER LOSS

The most common cause of engine power loss is mismanagement of fuel. Therefore, the first step to take after engine power loss is to move the fuel selector to the tank not being used. This will often restore power even if there is no apparent reason for the engine to stop on the tank being used.

If changing to another tank does not restore power:

1. Check fuel pressure - if electric fuel pump is off, turn it ON.
2. Push mixture control to full RICH.
3. Check ignition switch. Turn to best operating magneto - LEFT, RIGHT, or BOTH.

APPROACH AND LANDING

Before landing check list:

1. Seat backs - erect
2. Safety belts/harness - fastened
3. Fuel - on proper tank
4. Electric fuel pump - on
5. Mixture - rich
6. Flaps - set (125 MPH)

The airplane should be trimmed to an approach speed of about 85 MPH with flaps up. The flaps can be lowered at speeds up to 125 MPH, if desired, and the approach speed reduced 3 MPH for each additional notch of flaps. Carburetor heat should not be applied unless there is an indication of carburetor icing, since the use of carburetor heat causes a reduction of power which could be critical should a go-around be necessary. Full throttle operation with carburetor heat on is likely to cause detonation.

The amount of flap used during landings and the speed of the airplane at contact with the runway should be varied according to the landing surface, wind conditions, and airplane loading. It is generally good practice to contact the ground at the minimum possible safe speed consistent with existing conditions.

Normally, the best technique for short and slow landings is to use full flap and enough power to maintain the desired airspeed and approach flight path. Reduce the airspeed during flareout and contact the ground at close to stalling speed. After ground contact hold the nose wheel off as long as possible. As the airplane slows down, drop the nose and apply the brakes. There will be less chance of skidding the tires if the flaps are retracted before applying the brakes. Braking is most effective when back pressure is applied to the control wheel, putting most of the airplane weight on the main wheels. In high wind conditions, particularly in strong crosswinds, it may be desirable to approach the ground at higher than normal speeds with partial or no flaps.

STOPPING ENGINE

At the pilot's discretion, the flaps should be raised and the electric fuel pump turned off. After parking, the radios should be turned off and the engine stopped by putting the mixture control in idle cut-off. The throttle should be left full aft to avoid engine vibration while stopping. The magneto and master switches should be turned off and the parking brake set.

AIRSPPEED DATA

All airspeeds quoted in this manual are calibrated unless otherwise noted. Calibrated airspeed is indicated airspeed corrected for instrument and position errors. The following table gives the correlation between indicated airspeed and calibrated airspeed if zero instrument error is assumed. This calibration is valid only when flown at maximum gross weight in level flight.

AIRSPPEED CORRECTION TABLE

Flaps 0°										
IAS - MPH	60	70	80	90	100	110	120	130	140	150
CAS - MPH	66	74	82	90	99	108	117	126	135	144
Flaps 40°										
IAS - MPH	60	70	80	90	100	110	120			
CAS - MPH	65	73	81	89	98	107	116			

MOORING

The airplane can be moved on the ground with the aid of the optional nose wheel tow bar stowed in the baggage compartment. Tie-down ropes may be attached to rings under each wing and to the tail skid. The aileron and stabilator controls should be secured by looping the seat belt through the control wheel and pulling it snug. The rudder is held in position by its connection to the nose wheel steering and normally does not have to be secured. The flaps are locked when in the full up position and should be left retracted.

WEIGHT AND BALANCE

It is the responsibility of the owner and pilot to determine that the airplane remains within the allowable weight vs. center of gravity envelope while in flight. For weight and balance data, see the Weight and Balance Section of this manual.

CHEROKEE WARRIOR

EMERGENCY LOCATOR TRANSMITTER*

The Emergency Locator Transmitter (ELT), when installed, is located in the aft portion of the fuselage just below the stabilator leading edge and is accessible through a plate on the right side of the fuselage. It is an emergency locator transmitter which meets the requirements of FAR 91.52. It is automatically activated by a longitudinal force of 5 to 7 g's and transmits a distress signal on both 121.5 MHz and 243.0 MHz for a period of from 48 hours in low temperature areas up to 100 hours in high temperature areas. The unit operates on a self-contained battery.

The battery has a useful life of four years. However, to comply with FAA regulations it must be replaced after two years of shelf life or service life. The battery should also be replaced if the transmitter has been used in an emergency situation or if accumulated test time exceeds one hour. The replacement date is marked on the transmitter label.

On the unit itself is a three position selector switch placarded "OFF," "ARM," "ON." The "ARM" position is provided to set the unit to the automatic position so that it will transmit only after impact and will continue to transmit until the battery is drained to depletion or until the switch is manually moved to the "OFF" position. The "ARM" position is selected when the transmitter is installed at the factory and the switch should remain in that position whenever the unit is installed in the airplane. The "ON" position is provided so the unit can be used as a portable transmitter or in the event the automatic feature was not triggered by impact or to periodically test the function of the transmitter.

Select the "OFF" position when changing the battery, when rearming the unit if it has been activated for any reason, or to discontinue transmission.

NOTE

If the switch has been placed in the "ON" position for any reason, the "OFF" position has to be selected before selecting "ARM." If "ARM" is selected directly from the "ON" position the unit will continue to transmit in the "ARM" position.

A pilot's remote switch, located on the left side panel, is provided to allow the transmitter to be controlled from inside the cabin. The pilot's remote switch is placarded "ON," "ARM," "OFF RESET." If the pilot's remote switch has been placed in the "ON" position for any reason, the "OFF RESET" position must be selected for one second before the switch is placed in the "ARM" position.

The unit is equipped with a portable antenna to allow the locator to be removed from the airplane in case of an emergency and used as a portable signal transmitter.

*Optional equipment

The locator should be checked during the ground check to make certain the unit has not been accidentally activated. Check by tuning a radio receiver to 121.5 MHz. If there is an oscillating sound, the locator may have been activated and should be turned off immediately. Reset to the "ARM" position and check again to insure against outside interference.

NOTE

If for any reason a test transmission is necessary, the operator must first obtain permission from a local FAA/FCC representative (or other applicable Authority). Test transmission should be kept to a minimal duration.



**CENTURY IIB
AUTOPILOT FLIGHT SYSTEM**

PILOT'S OPERATING HANDBOOK

MARCH 1981
68S75

NOTICE

This manual contains general information on the operation of the Century IIB Autopilot. Specific FAA Approved information on special techniques, limitations and emergency procedures of a particular model airplane are contained in either an Airplane Flight Manual Supplement or a Limitations Placard. Be sure and familiarize yourself with the information contained, therein, before flight.

CAUTION

This autopilot system uses the pilot's panel mounted heading and attitude gyros for sensing. In the event of a gyro failure or a vacuum (or air) supply system failure, autopilot operation must not be attempted.

INTRODUCTION

The Century Flight Systems, Inc. Century IIB is a light weight automatic flight system utilizing an advanced electronic design for maximum performance and utility. Operating on the versatile 5000 cycle audio frequency, the Century IIB represents a design concept, pioneered by Century Flight Systems, Inc., in which the conventional follow-up or control position feedback signals are replaced by solid state analytical computers. In addition to providing a more stable and adaptable platform, the new system can cope with uneven fuel loads and directional mistrim without the usual directional errors.

Roll responses are time controlled for human-like control action and smooth heading changes.

This manual describes the basic characteristics of each function and its relationship to other functions on the flight system. Maximum utility will be realized after familiarization and practice.

TABLE OF CONTENTS

CAUTION AND NOTICE	2
INTRODUCTION	3
TABLE OF CONTENTS	4
 DESCRIPTION OF COMMAND FUNCTIONS	
<u>AUTOPILOT</u>	
COMMAND CONSOLE.....	3
ROLL ENGAGEMENT	4
ROLL COMMAND KNOB.....	4
HEADING MODE	5
COURSE SELECTOR D.G.	5
 <u>LATERAL GUIDANCE SYSTEM</u>	
COUPLER MODE SELECTOR.....	6
OMNI MODE	7
NAV MODE	7
HEADING MODE	8
LOCALIZER - NORMAL MODE	8
LOCALIZER - REVERSE MODE	8
 GENERAL OPERATING INSTRUCTIONS	
PREFLIGHT INSTRUCTIONS.....	9
AUTOPILOT ENGAGE SYSTEM.....	10
LATERAL GUIDANCE SYSTEM OPERATION.....	10
VOR NAVIGATION	12
VOR APPROACH	14
ILS APPROACH- NORMAL	16
ILS APPROACH- REVERSE (BACK COURSE)	18
 AIRCRAFT TRIM EFFECTS	 20
 AIR FILTER INFORMATION	 21
 NOTES	 22
 CENTURY FLIGHT SYSTEMS, INC. AUTOPILOT WARRANTY	 23

COMMAND CONSOLE




FIG.1

The Century IIB Console is designed to provide convenient finger tip command of the basic roll and heading functions. The lucite panel incorporates optically engineered night lighting with revisions for dimming control through the standard aircraft rheostat.

ROLL (AILERON) ENGAGEMENT

FIG.2

The Century IIB incorporates a fail safe electrical engage and disengage mechanism in the roll servo which is operated by the A/P ON-OFF Rocker Switch in the console. When only this switch is engaged, the autopilot is responsive to the roll command knob on the center console.

ROLL COMMAND KNOB

FIG.3

The roll command knob may be used to maneuver the aircraft up to approximately 30° of bank right or left. The centered position represents approximate wings level flight. When the Heading mode switch is engaged the roll knob is removed from the autopilot circuit and is ineffective.




FIG. 4

HEADING MODE

The heading mode rocker switch is used when turning the aircraft to a preselected heading on the Course Selector D.G. or when conducting course intercepts or tracking. Activating this switch removes the roll command knob from the autopilot circuit and adds the D.G. heading and coupler functions as basic autopilot inputs. The Course Selector D.G. and coupler mode selector should be set prior to engagement of the heading mode. (See Section on Coupler Operations when optional coupler is installed).




FIG. 5

COURSE SELECTOR D.G.

The course selector D.G. replaces the standard directional gyro and provides a fully visible, 360° course indication. The D.G. dial is marked in 5° intervals and numbered each 30° around its azimuth. A center indice is provided at the top to align selected headings. Additional indices are located each 45° to facilitate rapid turn selection without mental arithmetic. Any heading may be selected, either before or after engagement, and turns up to 160° may be programmed directly, either right or left. If the course selector indicator is rotated beyond 180° from the D.G. card heading, the autopilot will turn in the shortest direction to reach the selected heading.

In normal operation the maximum bank in HDG mode is 20°. The D.G. card is set with the caging knob on the left of the instrument and the course selector indicator is rotated by the HDG. knob on the right. Direction of response to rotation for both knobs is conventional.


LATERAL GUIDANCE SYSTEM

FIG. 6

COUPLER MODE SELECTOR

The Century flight Systems, Inc. Lateral Guidance System contains a completely automatic, analog computer that directs the autopilot in both VOR and ILS navigation. The system contains a five position coupler mode selector switch which mounts in the instrument panel. Nominal interception angles are 45° and an automatic 15° crosswind correction capability is provided. The complete capture, intercept and tracking sequence is accomplished automatically without monitoring or multiple switching.




Figure 7

OMNI MODE

When in the OMNI MODE position, the system is coupled to the Omni Bearing Indicator. To select a desired course for interceptor tracking, always set both the OMNI course Selector and the D.G. Course Indicator to the desired course. All headings will then be controlled by the OMNI radio signals. A full deflection on the OMNI Indicator will produce a 45° interception angle. With less than full deflection, the system will automatically direct a smooth, tangential intercept to arrive over the radial with crosswind correction established.

The same dynamic intercept is accomplished whether 2 miles or maximum reception distance from station. Below approximately 2 miles autopilot bank limitations will allow a slight overshoot of the selected radial.




Figure 8

NAV MODE

NAV Mode operation is initiated in the same manner and serves the same functions as Omni Mode. The NAV, however, incorporates an extended time delay in the computer circuitry which reduces reaction to short term needle deflections. The NAV Mode is recommended for enroute navigation or anytime autopilot response to short term needle deflections becomes excessive. The NAV Mode should not be used for close in VOR approach work, as close in work requires the proportioned dynamic response provided by the Omni Mode.




Figure 9

HEADING MODE

When in the HDG mode the Century IIB Autopilot will function as described on pages 4 and 5 of this manual.




Figure 10

LOCALIZER (Normal) MODE

In the LOC Norm mode, the system adjusts its sensitivity to accommodate the 5° localizer course width. Since the localizer course width is only 1/4 as wide as the nominal omni indication, additional damping circuits are included to produce smoother, more optimum intercept and track maneuvers. Intercept angles of 45° are automatic with tangential intercepts outside the outer marker and automatic crosswind correction. As with the Omni Mode, the Course Selector D.G. must be set to correspond with the desired magnetic course.




Figure 11

LOCALIZER (Reverse) MODE

The Century Flight Systems, Inc. Lateral Guidance System is equipped with the Localizer Reverse feature to permit automatic back course approaches and to allow outbound tracking on the Front Course prior to procedure turn. The features of LOC-REV are identical to the LOC-NORM except that the aircraft will fly away from the Localizer Indicator Needle instead of toward it. When using the LOC-REV mode, the Course Selector Indicator must be set to the reciprocal of the Front Course heading.

GENERAL OPERATIONS

The Century IIB and optional coupler are FAA approved on each make and model aircraft under a "Supplemental Type Certificate" STC

There are no restrictions to operations in turbulence and as a general rule autopilot operation in turbulence will result in smoother operation.

Autopilot operating limitations and any special limitations will be specified on the Limitations Placard or in the Airplane Flight Manual Supplement. This should be carefully read and understood.

Autopilot override forces are adjusted to the servo power output requirements of each particular aircraft. The autopilot may be overridden by the pilot without damage to the system.

NOTE: Only Century Flight Systems, Inc. trained specialists at approved service centers should adjust servo torque outputs.

PILOT'S PREFLIGHT PROCEDURE

1. With engines running and gyros erected, check vacuum readings. Should be 4.75" to 5.00" HG.
2. With the autopilot off, place coupler mode selector on HDG. position. Center roll knob and D.G. course selector indicator.
3. Engage roll switch, rotate roll command knob left and right and note that the control wheel responds in the proper direction.
4. Engage the heading mode switch and rotate course selector indicator to either side. Note roll servo response; again, without aerodynamic response, servo action is unlimited.
5. Override the autopilot at the control wheel in both directions. Force required should be approximately 15 lbs. At wheel edge dependent upon aircraft model.
6. Disengage autopilot before takeoff.

AUTOPILOT ENGAGE SEQUENCE (IN FLIGHT)

1. Trim aircraft to a wings level flight attitude.
2. Center roll knob and engage autopilot "ON" switch.
3. If navigation mode selector is installed select "HDG" mode.
4. Center D.G. course selector indicator and engage heading mode switch.

LATERAL GUIDANCE SYSTEM OPERATION

Perform Steps 1-4 above then continue below:

5. Match course selector indicator to selected VOR or ILS course.
6. Select Lateral Guidance Mode desired.

VOR NAVIGATION (See Fig. 12)**1. TO INTERCEPT**

- A. Using Omni Bearing Selector (OBS) dial desired course, inbound or outbound.
- B. Set identical heading on course Selector D.G.
- C. After aircraft has stabilized, position coupler mode selector knob to OMNI mode.

NOTE

If aircraft is positioned less than 45° from selected radial aircraft will intercept before station. If more than 45°, interception will occur after station passage.

- D. As aircraft nears selected radial, interception and crosswind correction will be automatically accomplished without further switching.
- E. As the aircraft nears the OMNI station, (1/2 mile) the zone of confusion will direct an "S" turn in alternate directions as the OMNI indicator needle swings. This alternate banking, is an indication that station passage is imminent.

2. TO SELECT NEW COURSE

- A. To select any outbound course or radial, dial the new course into the Course Selector D.G.
- B. Rotate OBS to the same course.
- C. Aircraft will automatically turn, to the interception heading for the new course.

3. TO CHANGE STATIONS

- A. If same course is desired, merely tune receiver to new station frequency.
- B. If different course is desired, position coupler mode selector to HDG mode.
- C. Dial Course Selector D.G. to new course.
- D. Dial OBS to new course.
- E. Position mode selector to OMNI mode.

VOR NAVIGATION




FIG. 12

VOR APPROACH (See Fig. 13)

1. Track inbound to station as described in VOR Navigation Section.
2. At station passage dial outbound course on Course Selector D.G. and on OBS.
3. After established on outbound radial, position coupler mode selector to HDG mode and select outbound procedure turn heading.
4. To turn inbound, dial inbound procedure turn heading on Course Selector D.G. dialing in desired direction of turn. Set OBS to inbound course.
5. When turned to within 90° or inbound course, dial Course Selector Indicator to inbound course and position coupler mode selector to OMNI mode.
6. If holding pattern is desired, position mode selector to HDG mode at station passage inbound and select outbound heading in direction of turn.
7. To turn inbound, dial inbound course on Course Selector inbound.
8. When turned to within 90° of inbound radial, position coupler mode selector on OMNI mode.

NOTE

For precise tracking over Omni Station, without "S" turn, position coupler mode selector on HDG until station passage

VOR APPROACH




FIG. 13

ILS APPROACH--NORMAL (See Fig.14)

1. To Intercept Outbound:
 - A. Dial ILS Southbound course on Course Selector D.G.
 - B. When stabilized; position mode selector to LOC REV mode.

2. For Procedure Turn:
 - A. Following outbound course interception and when beyond outer marker, position mode selector to HDG and dial outbound procedure turn heading.
 - B. To turn inbound, dial inbound procedure turn heading in direction of turn.

3. When within 90° of ILS inbound course, dial inbound course on Course Selector D.G. and position mode selector to LOC NORM mode.

4. At the Decision Height (DH), or when missed approach is elected, position mode selector to HDG mode and execute missed approach procedure.

ILS APPROACH- NORMAL




FIG. 14

ILS APPROACH--BACK COURSE (See Fig. 15)

1. To Intercept Back Course Outbound:
 - A. Dial ILS Front Course heading on Course Selector D.G.
 - B. When stabilized, position mode selector to LOC NORM mode.

2. For Procedure Turn:
 - A. After interception and when beyond final approach fix, position mode selector to HDG and dial outbound procedure turn heading.
 - B. To turn inbound, dial inbound procedure turn heading in direction of turn.

3. When within 90° of inbound course, dial inbound course on Course Selector D.G. and position mode selector on LOC REV mode.

4. Position mode selector to HDG mode to prevent "S" turn over ILS station near runway threshold.

5. Execute missed approach procedure.

ILS APPROACH - BACK COURSE




FIG. 15

CAUTION

When electrical power is first applied to the NSD-360A instrument, the compass card may rotate or "slew" rapidly. This is NOT an indication that the compass system is orienting itself to the proper magnetic heading. The proper heading orientation must be verified and set prior to takeoff and should be verified prior to approach to landing using the magnetic compass.

CAUTION

The NSD has an optional slaving feature that requires initial heading setting on start-up. Subsequent resetting of the heading card, required manually on non-slaved versions, is automatically accomplished with the slaved version.

Proper heading synchronization must be verified on both non-slaved and slaved NSD-360A units. This is accomplished by comparing the heading displayed under the lubber line with the magnetic compass...

The NSD-360A incorporates a heading warning flag to warn of loss of either air or electronic power. Appearance of the flag during flight should be sufficient grounds to question the validity of the displayed heading. In slaved versions, the slaving meter should oscillate about a 45° point to show that the slaving circuits are accomplishing their function. Should the needle remain motionless or either vertical or horizontal for an extended period (two minutes) in level flight, the heading should be manually set using the magnetic compass and the performance of the heading card observed. If this condition persists, set the slaving mode switch to SL#2 on free gyro. In free gyro mode, the instrument must be periodically reset to manually counteract the effects of gyro precession.

AIRCRAFT TRIM EFFECTS




FIG. 16

An important point to remember is that while the Century IIB Autopilot is maintaining heading the airplane should never fly with a wing low. This statement applies equally to an airplane without an autopilot.

Consider the effect of rudder trim in the above drawing (Fig. 16). Viewing the airplane from the rear, note that with left rudder applied the right wing must be lowered to offset the rudder effect and keep the heading constant, i.e., the left turn effect of the rudder is canceled by the right turn effect of the bank.

Since the autopilot is slaved to heading this is exactly what it will do in order to hold a heading when the rudder is out of trim.

Thus when operating on autopilot heading mode, if the aircraft flies with one wing low while maintaining heading, this indicates the rudder trim is required in the direction of the low wing.

AIR FILTER

AIR FILTER AND ELEMENT

The Century flight Systems, Inc. 1X314 central air filter is incorporated on all 3" gyro systems with the exception of aircraft with original equipment filters of like quality.

The 1X314 filter system uses the 51A5 replaceable filter element which is capable of removing 97% of all contaminating substances above 3 microns. This includes tobacco tars that would otherwise be harmful to bearings and vanes. Because of this exceptional filtering ability contaminants tend to accumulate at higher rate than in other types. It is therefore considered necessary that filter elements be replaced at each 100 hour period and that filters subjected to tobacco tars, industrial smoke and like environment, be inspected each 50 hours for possible replacement.

Gyro warranty is dependent upon following this procedure.

NOTES

Effective: July 4, 1975

LIMITED WARRANTY CENTURY FLIGHT SYSTEMS, INC. AUTOPILOT

Each new Century Flight Systems, Inc. Autopilot is warranted by the manufacturer to be free from defects in material and workmanship under normal use, subject to the following conditions:

1. Century Flight Systems, Inc. Will through its designated service facilities at its option either repair or replace new components which, shall within (12 months after date of installation, be found, to Century Flight Systems, Inc. Satisfaction, to have been defective in material or workmanship under normal use.
2. The warranty registration must be signed and returned to Century Flight Systems, Inc. within ten days of equipment installation date. In the event that the registration card is not returned within this time, the date of shipment from the factory will be deemed to be the installation date.
3. This warranty will not apply to any product which has been installed, repaired, or altered in any way whatsoever in Century Flight Systems, Inc. Opinion to adversely affect its performance or reliability, or which has been subject to mis-use, contamination, negligence, or accident.
4. Cost of transportation, removal or reinstallation are at the option of Century Flight Systems, Inc.
5. This is Century Flight Systems, Inc. sole express warranty with respect to the goods supplied herein. CENTURY FLIGHT SYSTEMS, INC. MAKES NO OTHER EXPRESS WARRANTY OF ANY KIND WHATSOEVER. CENTURY FLIGHT SYSTEMS, INC. EMPLOYEES MAY HAVE MADE ORAL STATEMENTS ABOUT THE PRODUCTS DESCRIBED IN THIS CONTRACT. SUCH STATEMENTS DO NOT CONSTITUTE WARRANTIES, SHALL NOT BE RELIED UPON BY THE CUSTOMER, AND ARE NOT PART OF THE SALE CONTRACT.
6. THE DURATION OF ANY IMPLIED WARRANTY, AND OF ALL WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL BE LIMITED TO (12) MONTHS COMMENCING AT DATE OF INSTALLATION TO THE FULL EXTENT PERMITTED BY APPLICABLE LAW, CONSEQUENTIAL DAMAGE OF BREACH OF ANY WARRANTY ARE HEREBY DISCLAIMED AND EXCLUDED BY CENTURY FLIGHT SYSTEMS, INC.

Century Flight Systems, Inc.
P.O. Box 610
Municipal Airport
Mineral Wells, Texas
76067
August 1983

RECYCLING TIPS

OPERATING TIPS

Operating Tips 8-1

OPERATING TIPS

The following Operating Tips are of particular value in the operation of the airplane.

1. Learn to trim for takeoff so that only a slight back pressure on the wheel is required to lift the airplane from the ground.
2. The best speed for takeoff is about 60 MPH under normal conditions. Trying to pull the airplane off the ground at too low an airspeed decreases the controllability of the airplane in event of engine failure.
3. Flaps may be lowered at airspeeds up to 125 MPH. To reduce flap operating loads, it is desirable to have the airplane at a slower speed before extending the flaps.
4. Before attempting to reset any circuit breaker, allow a two to five minute cooling off period.
5. Before starting the engine, check that all radio switches, light switches and the pitot heat switch are in the off position to prevent an overloaded condition when the starter is engaged.
6. The overvoltage relay protects the electronics equipment from a momentary overvoltage condition (approximately 16.5 volts and up), or a catastrophic regulator failure. In the event of a momentary condition, the relay will open and the ammeter will indicate "0" output from the alternator. The relay may be reset by switching the ALT switch to OFF for approximately 1 second and then returning the ALT switch to ON.
7. The vacuum gauge monitors the pressure available to assure the correct operating speed of the vacuum driven gyroscopic flight instruments. It also monitors the condition of the common air filter by measuring the flow of air through the filter.

If the vacuum gauge does not register $5'' \pm .10''$ Hg at 2000 RPM, the following items should be checked before flight:

- a. Common air filter could be dirty or restricted.
 - b. Vacuum lines could be collapsed or broken.
 - c. Vacuum pump could be worn.
 - d. Vacuum regulator could be improperly adjusted. The pressure, even though set correctly, can read lower under two conditions: (1) Very high altitude - above 12000 feet, (2) Low engine RPM - usually on approach or during training maneuvers. This is normal and should not be considered a malfunction.
8. The shape of the wing tanks is such that in certain maneuvers, the fuel may move away from the tank outlet. If the outlet is uncovered, the fuel flow may be interrupted, resulting in a temporary loss of power. Pilots can prevent inadvertent uncovering of the outlet by avoiding maneuvers which could result in the uncovering of the outlet.

Running turning takeoffs should be avoided, as fuel flow interruption may occur if the tank in use is not full.

Prolonged slips or skids in any pitch attitude or other unusual maneuvers which could cause uncovering of the fuel outlet must be avoided when the tank being used is not full.

CHEROKEE WARRIOR


9. Anti-collision lights should not be operating when flying through overcast and clouds, since reflected light can produce spacial disorientation. Do not operate strobe lights when taxiing in the vicinity of other aircraft.
10. The rudder pedals are suspended from a torque tube which extends across the fuselage. The pilot should become familiar with the proper positioning of his feet on the rudder pedals so as to avoid interference with the torque tube when moving the rudder pedals or operating the toe brakes.

PERFORMANCE CHARTS


PERFORMANCE CHARTS

Altitude Conversion Chart	9-1
Takeoff Distance vs Density Altitude	9-2
Rate of Climb vs Density Altitude	9-3
Engine RPM vs Density Altitude	9-4
True Airspeed vs Density Altitude (Best Power)	9-5
True Airspeed vs Density Altitude (Best Economy)	9-6
Range vs Density Altitude (Best Power)	9-7
Range vs Density Altitude (Best Economy)	9-8
Stall Speed vs Weight	9-9
Stall Speed vs Angle of Bank	9-10
Glide Distance vs Altitude	9-11
Landing Distance vs Density Altitude	9-12


PA-28-151 CHEROKEE




PA-28-151 CHEROKEE




PA-28-151 CHEROKEE




PA-28-151 CHEROKEE




PA-28-151 CHEROKEE




PA-28-151 CHEROKEE




PA-28-151 CHEROKEE




PA-28-151 CHEROKEE




PA-28-151 CHEROKEE




PA-28-151 CHEROKEE



PA-28-151 CHEROKEE



PA-28-151 CHEROKEE



HANDLING AND SERVICING

HANDLING AND SERVICING

Ground Handling	10-1
Towing	10-1
Taxiing	10-1
Parking	10-2
Mooring	10-2
Cleaning	10-3
Cleaning Engine Compartment	10-3
Cleaning Landing Gear	10-3
Cleaning Exterior Surfaces	10-4
Cleaning Windshield and Windows	10-4
Cleaning Headliner, Side Panels and Seats	10-4
Cleaning Carpets	10-5
Power Plant Induction Air Filter	10-5
Removal of Induction Air Filter	10-5
Installation of Induction Air Filter	10-5
Brake Service	10-7
Landing Gear Service	10-7
Propeller Service	10-8
Oil Requirements	10-8
Fuel System	10-9
Servicing Fuel System	10-9
Fuel Requirements	10-9
Filling Fuel Tanks	10-9
Draining Fuel Valves and Lines	10-9
Draining Fuel System	10-10
Tire Inflation	10-10
Battery Service	10-11
Winterization	10-11
Facts You Should Know	10-12
Preventive Maintenance	10-14
Required Service and Inspection Periods	10-15

HANDLING AND SERVICING

This section contains information on preventive maintenance. Refer to the PA-28-151 Service Manual for further maintenance procedures. Any complex repair or modification should be accomplished by a Piper Certified Service Center.

GROUND HANDLING

TOWING

The airplane may be moved by using the nose wheel tow bar available with the airplane, or by power equipment that will not damage or cause excess strain to the nose gear assembly. The tow bar is stowed in the baggage compartment.

CAUTION

When towing with power equipment, do not turn the nose gear beyond its turning radius in either direction as this will result in damage to the nose gear and steering mechanism.

CAUTION

Do not tow the airplane when the controls are secured.

TAXIING

Before attempting to taxi the airplane, ground personnel should be instructed and approved by a qualified person authorized by the owner. Engine starting and shut-down procedures and taxiing techniques should be covered. When it is ascertained that the propeller back blast and taxi areas are clear, power should be applied to start the taxi roll, and the following checks should be performed:

- a. Taxi forward a few feet and apply the brakes to determine their effectiveness.
- b. While taxiing, make slight turns to ascertain the effectiveness of the steering.
- c. Observe wing clearances when taxiing near buildings or other stationary objects. If possible, station an observer outside to guide the airplane.
- d. When taxiing on uneven ground, avoid holes and ruts.
- e. Do not operate the engine at high RPM when running up or taxiing over ground containing loose stones, gravel, or any loose material that might cause damage to the propeller blades.

PARKING

When parking the airplane, be sure that it is sufficiently protected from adverse weather conditions and that it presents no danger to other aircraft. When parking the airplane for any length of time or overnight, it is suggested that it be moored securely.

- a. To park the airplane, head it into the wind if possible.
- b. Set the parking brake by pulling back on the brake lever and depressing the knob on the handle. To release the parking brake, pull back on the handle until the catch disengages; then allow the handle to swing forward.

CAUTION

Care should be exercised when setting brakes that are overheated or during cold weather when accumulated moisture may freeze a brake.

- c. Aileron and stabilator controls may be secured with the front seat belt. Wheel chocks may be used if they are available.

MOORING

The airplane should be moored for immovability, security, and protection. The following procedures should be used for the proper mooring of the airplane:

- a. Head the airplane into the wind, if possible.
- b. Retract the flaps.
- c. Immobilize the ailerons and stabilator by looping the seat belt through the control wheel and pulling it snug.
- d. Block the wheels.
- e. Secure tie-down ropes to the wing tie-down rings and to the tail skid at approximately 45 degree angles to the ground. When using rope of non-synthetic material, leave sufficient slack to avoid damage to the airplane should the ropes contract.

CAUTION

Use bowline knots, square knots, or locked slip knots. Do not use plain slip knots.

NOTE

Additional preparations for high winds include using tie-down ropes from the landing gear forks and securing the rudder.

- f. Install a pitot head cover if one is available. Be sure to remove the pitot head cover before flight.
- g. Cabin and baggage doors should be locked when the airplane is unattended.

CLEANING

CLEANING ENGINE COMPARTMENT

Before cleaning the engine compartment, place a strip of tape over the magneto vents to prevent any solvent from entering these units.

- a. Place a large pan under the engine to catch waste.
- b. With the engine cowling removed, spray or brush the engine with solvent or a mixture of solvent and degreaser. In order to remove especially heavy dirt and grease deposits, it may be necessary to brush areas that were sprayed.

CAUTION

Do not spray solvent into the alternator, vacuum pump, starter, or air intakes.

- c. Allow the solvent to remain on the engine from five to ten minutes. Then rinse the engine clean with additional solvent and allow it to dry.

CAUTION

Do not operate the engine until excess solvent has evaporated or otherwise been removed.

- d. Remove the protective tape from the magnetos.
- e. Lubricate the controls, bearing surfaces, etc., in accordance with the Lubrication Chart.

CLEANING LANDING GEAR

Before cleaning the landing gear, place a cover of plastic or a similar waterproof material over the wheel and brake assembly.

- a. Place a pan under the gear to catch waste.
- b. Spray or brush the gear area with solvent or a mixture of solvent and degreaser. In order to remove especially heavy dirt and grease deposits, it may be necessary to brush areas that were sprayed.
- c. Allow the solvent to remain on the gear from five to ten minutes. Then rinse the gear with additional solvent and allow it to dry.
- d. Remove the cover from the wheel and remove the catch pan.
- e. Lubricate the gear in accordance with the Lubrication Chart.

CLEANING EXTERIOR SURFACES

The airplane should be washed with a mild soap and water. Harsh abrasives or alkaline soaps or detergents could make scratches on painted or plastic surfaces or could cause corrosion of metal. Cover areas where cleaning solution could cause damage. To wash the airplane, use the following procedure:

- a. Flush away loose dirt with water.
- b. Apply cleaning solution with a sponge, a soft cloth, or a soft bristle brush.
- c. To remove exhaust stains, allow the solution to remain on the surface longer.
- d. To remove stubborn oil and grease stains use a cloth dampened with naphtha.
- e. Rinse all surfaces thoroughly.
- f. Any good automotive wax may be used to protect and preserve painted surfaces. Soft cleaning cloths or a chamois should be used to prevent scratches when cleaning or polishing. A heavier coating of wax on the leading surfaces will reduce the abrasion problems in these areas.

CLEANING WINDSHIELD AND WINDOWS

A certain amount of care is needed to keep the windows clean and unmarred. The following procedure is recommended:

- a. Remove dirt, mud, and other loose particles from exterior surfaces with clean water.
- b. Wash with mild soap and clean water or with aircraft plastic cleaner. Use a soft cloth or sponge in a straight back and forth motion. Do not rub harshly.
- c. Remove oil or grease with a cloth moistened with kerosene.

CAUTION

Do not use gasoline, alcohol, benzene, carbon tetrachloride, thinner, acetone, or window cleaning sprays.

- d. After cleaning plastic surfaces, apply a thin coat of hard polishing wax. Rub lightly with a soft cloth. Do not use a circular motion.
- e. A severe scratch or mar in plastic can be removed by rubbing out the scratch with jeweler's rouge. Smooth both sides and apply wax.

CLEANING HEADLINER, SIDE PANELS AND SEATS

- a. Clean headliner, side panels and seats with a whisk broom, dusting cloth, or a vacuum cleaner.
- b. Soiled upholstery may be cleaned with a good upholstery cleaner suitable for the material. Carefully follow the manufacturer's instructions. Avoid soaking or harsh rubbing.

CAUTION

Solvent cleaners require adequate ventilation.

CLEANING CARPETS

To clean carpets, first remove loose dirt with a vacuum or a whisk broom. For soiled spots and stubborn stains use a nonflammable dry cleaning fluid. Floor carpets may be removed and cleaned like any household carpet.

POWER PLANT INDUCTION AIR FILTER

The wet-type polyurethane foam air filter must be inspected at least once every fifty hours. Under extremely adverse operating conditions, it may be necessary to inspect the filter more frequently. The filter is disposable and inexpensive and a spare should be kept on hand for a rapid replacement.


REMOVAL OF INDUCTION AIR FILTER

The filter is located in the lower right front of the engine compartment and may be removed by the following procedure:

- a. Open the right side of the engine cowling.
- b. Loosen each of the four quarter-turn fasteners securing the air filter cover.
- c. Separate the cover and remove the filter.
- d. Inspect the filter. If it is excessively dirty or shows any damage, replace it immediately.

INSTALLATION OF INDUCTION FILTER

When replacing the filter, install the filter in the reverse order of removal.



Brake System

BRAKE SERVICE

The brake system is filled with MIL-H-5606 (petroleum base) hydraulic brake fluid. The fluid level should be checked periodically or at each 50 hour inspection and replenished when necessary. The brake reservoir is located on the upper left side of the fire wall in the engine compartment. If the entire system must be refilled, fill with fluid under pressure from the brake end of the system. This will eliminate air from the system.

No adjustment of brake clearances is necessary. If after extended service brake blocks become excessively worn, they should be replaced with new segments.

LANDING GEAR SERVICE

The main landing gears use Cleveland 6.00 x 6 wheels, and the nose gear carries a Cleveland 5.00 x 5 wheel. All three tires are 4 ply rating, Type III tires with tubes; the main gear tires are 6.00 x 6 and the nose gear tire is 5.00 x 5. (See Tire Inflation, this Section.)

Main wheels are removed by taking off the hub cap, pin, axle nut, and the two bolts holding the brake segment in place, after which the wheel slips easily from the axle.

The nose wheel is removed by taking off the axle nut and washer from one side, sliding out the axle rod and plugs, lightly tapping out the axle tube, and then removing the wheel and spacer tubes from between the fork. Wheels are replaced by reversing the procedure.

Tires are removed from the wheels by deflating the tire, removing the through bolts, and separating the wheel halves.

Landing gear oleo struts should be checked for proper strut exposure and visible leaks. The required extensions for the struts under normal static load (empty weight of airplane plus full fuel and oil) are 3.25 inches for the nose gear and 4.50 inches for the main gear. If the strut exposure is below that required, it should be determined whether air or oil is needed by first raising the airplane on jacks. Depress the valve core to allow air to escape from the strut housing chamber. Remove the filler plug and slowly raise the strut to full compression. If the fluid is then visible up to the bottom of the filler plug hole, only proper extension with air is required.

If fluid is below the bottom of the filler plug hole, oil should be added. Replace the plug with the valve core removed. Then attach a clear plastic hose to the valve stem of the filler plug and submerge the other end in a container of hydraulic fluid (MIL-H-5606). Fully compress and extend the strut several times, thus drawing fluid from the container and expelling air. The torque link assembly must be disconnected to let the strut be extended a minimum of 10 inches. (The nose gear torque links need not be disconnected.) DO NOT allow the strut to extend beyond 12 inches. When air bubbles cease to flow through the hose, fully compress the strut, remove the filler plug, and again check the fluid level. When the fluid level is correct, disconnect the hose, reinstall the valve core, the filler plug, and the main gear torque links.

With the fluid in the strut housing at the proper level, attach a strut pump to the air valve. With the airplane on the ground under normal static load, inflate the oleo strut to the proper strut exposure.

CHEROKEE WARRIOR

In jacking the airplane for landing gear or other service, two hydraulic jacks and a tail stand should be used. At least 250 pounds of ballast should be placed on the tail stand before jacking the airplane. The hydraulic jacks are placed under the jack points on the underside of the wings, and the airplane is jacked up until the tail stand can be attached to the tail skid. After attaching the tail stand and adding the ballast, the jacking can be continued until the airplane is at the desired height.

The steering arms from the rudder pedals to the nose gear are adjusted at the rudder pedals or at the nose wheel by turning in or out the threaded rod end bearings. Adjustments are normally made at the forward end of the rods and should be done in such a way that the nose wheel is in line with the fore and aft axis of the airplane when the rudder pedals and rudder are centered. Alignment of the nose wheel can be checked by pushing the airplane back and forth with the rudder centered to determine that the plane follows a perfectly straight line.

The turning arc of the nose wheel is 30 degrees either side of center and is factory adjusted at stops on the bottom of the forging. The turning radius of the nose wheel is 13 feet.

The rudder bar stops should be carefully adjusted so that the rudder bar reaches its full travel just after the rudder hits its stops. This guarantees that the rudder will be allowed to move through its full travel.

PROPELLER SERVICE

The spinner and backing plate should be cleaned and inspected for cracks frequently. Before each flight the propeller should be inspected for nicks, scratches, or corrosion. If found, they should be repaired as soon as possible by a rated mechanic, since a nick or scratch causes an area of increased stress which can lead to serious cracks or the loss of a propeller tip. The back face of the blades should be painted when necessary with flat black paint to retard glare. To prevent corrosion, all surfaces should be cleaned and waxed periodically.

OIL REQUIREMENTS

The oil capacity of the Lycoming O-320-E3D series engines is 8 quarts and the minimum safe quantity is 2 quarts. It is recommended that the oil be changed every 50 hours and sooner under unfavorable operating conditions. The following grades are recommended for the specified temperatures:

Temperatures	Single Viscosity Grade	Multi-Viscosity Grade
Above 60° F	SAE 50	SAE 40 or SAE 50
Between 30° and 90° F	SAE 40	SAE 40
Between 0° and 70° F	SAE 30	SAE 40 or 20W-30
Below 10° F	SAE 20	SAE 20W-30

FUEL SYSTEM

SERVICING FUEL SYSTEM

At every 50 hour inspection, the fuel screen in the strainer will require cleaning. The strainer, located ahead of the fire wall, is accessible for cleaning through the left cowl door. After cleaning, a small amount of grease applied to the gasket will facilitate reassembly.

FUEL REQUIREMENTS

Aviation grade fuel with a minimum octane of 80/87 must be used in this airplane. Since the use of lower grades can cause serious engine damage in a short period of time, the engine warranty is invalidated by the use of lower octanes.

FILLING FUEL TANKS

Observe all safety precautions required when handling gasoline. Fuel is stored in two 25 U.S. gallon tanks (24 U.S. gallons usable). To obtain the standard quantity of 50 U.S. gallons (approximately 48 U.S. gallons usable), fill each tank to the top of the filler neck.

DRAINING FUEL VALVES AND LINES

The fuel system should be drained daily prior to first flight and after refueling to avoid the accumulation of water and sediment. Each fuel tank has an individual quick drain at the bottom inboard rear corner, and each fuel collector manifold has a drain under the wing and near the fuselage. Each of these four drains should be opened until sufficient fuel has flowed to ensure the removal of any contaminants.


The gascolator, located on the lower left front of the fire wall, is also equipped with a drain. It too should be checked for water or sediment accumulation. The gascolator drain is accessible from outside the nose section of the airplane.

A special bottle is provided for these fuel draining and checking operations.

To drain the lines from the tanks, the tank selector valve must be switched to each tank in turn with the electric fuel pump on and the gascolator drain valve opened.

CAUTION

When draining fuel, be sure that no fire hazard exists before starting the engine.



Fuel Drain

DRAINING FUEL SYSTEM

The bulk of the fuel may be drained by opening the individual drain on each tank. The remaining fuel in the lines may be drained through the fuel collector manifold drains and the gascolator drain. Any individual tank may be drained by closing the fuel selector valve and then draining the desired tank through its individual drain.

TIRE INFLATION

For maximum service from the tires, keep them inflated to the proper pressures. The main gear tires should be inflated to 24 psi and the nose gear should be inflated to 30 psi.

Interchange the tires on the main wheels if necessary to produce even wear. All wheels and tires are balanced before original installation, and the relationship of the tire, tube, and wheel should be maintained if at all possible. Unbalanced wheels can cause extreme vibration on takeoff. In the installation of new components, it may be necessary to rebalance the wheel with the tire mounted.

When checking the pressure, examine the tires for wear, cuts, bruises, and slippage.

BATTERY SERVICE

Access to the 12-volt battery is obtained by raising the rear seat and removing the cover of the battery box. The plastic battery box has a drain tube which is normally closed off with a cap and which should be opened occasionally to drain off any accumulation of liquid.

The battery should be checked for proper fluid level. **DO NOT** fill the battery above the baffle plates. **DO NOT** fill the battery with acid - use only water. A hydrometer check will determine the percent of charge in the battery.

If the battery is not up to charge, recharge starting at a 4 amp rate and finishing with a 2 amp rate. Quick charges are not recommended.

WINTERIZATION

For winter operation a winterization plate is installed on the inlet opening of the oil cooler. This plate should be installed whenever the ambient temperature reaches 50° F or less. The plate should be removed and stored in the cockpit when the ambient temperature exceeds 50° F.

FACTS YOU SHOULD KNOW

The Federal Aviation Administration (FAA) occasionally publishes **Airworthiness Directives (ADs)** that apply to specific groups of aircraft. They are mandatory changes and are to be complied with within a time limit set by the FAA. When an AD is issued, it is sent to the latest registered owner of the affected aircraft and also to subscribers of the service. The owner should periodically check with his Piper dealer or A & P mechanic to see whether he has the latest issued AD against his aircraft.

Piper Aircraft Corporation takes a **continuing interest** in having the owner get the most efficient use from his aircraft and keeping it in the best mechanical condition. Consequently, Piper Aircraft from time to time issues Service Bulletins, Service Letters and Service Spares Letters relating to the aircraft.

Service Bulletins are of special importance and should be complied with promptly. These are sent to the latest registered owners, distributors and dealers. Depending on the nature of the bulletin, material and labor allowances are usually applicable.

Service Letters deal with product improvements and service hints pertaining to the aircraft. They are sent to dealers and distributors so they can properly service the aircraft and keep it up to date with the latest changes. Owners should give careful attention to the Service Letter information.

Service Spares Letters offer improved parts, kits and optional equipment which were not available originally and which may be of interest to the owner.

If an owner is not having his aircraft serviced by an **Authorized Piper Service Center**, he should periodically check with a Piper dealer or distributor to find out the latest information to keep his aircraft up to date.

Piper Aircraft Corporation has a **Subscription Service** for the Service Bulletins, Service Letters and Service Spares Letters. This service is offered to interested persons such as owners, pilots and mechanics at a nominal fee, and may be obtained through Piper dealers and distributors. A Service Manual and revisions are available from a Piper dealer.

Pilot's Operating Manual supplements are distributed by the manufacturer as necessary. These revisions and additions should be studied and put into the operating manual to keep it up to date. This manual contains important information about the operation of the aircraft and should be kept with the aircraft at all times, even after resale. Every owner, to avail himself of the Piper Aircraft Service Back-Up, should stay in close contact with his Piper dealer or distributor so that he can receive the latest information.

If the owner desires to have his aircraft modified, he must obtain FAA approval for the alteration. **Major alterations** accomplished in accordance with Advisory Circular 43.13-2, when performed by an A & P mechanic, may be approved by the local FAA office. Major alterations to the basic airframe or systems not covered by AC 43.13-2 require a Supplemental Type Certificate.

The owner or pilot is required to ascertain that the following Aircraft Papers are in order and in the aircraft.

- a. To be displayed in the aircraft at all times:
 1. Aircraft Airworthiness Certificate Form FAA-1362B.
 2. Aircraft Registration Certificate Form FAA-500A.
 3. Aircraft Radio Station License Form FCC-404A, if transmitters are installed.
- b. To be carried in the aircraft at all times:
 1. Aircraft Flight Manual.
 2. Weight and Balance data plus a copy of the latest Repair and Alteration Form FAA-337, if applicable.
 3. Aircraft equipment list.

Although the aircraft and engine log books are not required to be in the aircraft, they should be made available upon request. Log books should be complete and up to date. Good records will reduce maintenance cost by giving the mechanic information about what has or has not been accomplished.

PREVENTIVE MAINTENANCE

The holder of a Pilot Certificate issued under FAR Part 61 may perform certain preventive maintenance described in FAR Part 43. This maintenance may be performed only on an aircraft which the pilot owns or operates and which is not used in air carrier service. The following is a list of the maintenance which the pilot may perform:

1. Repair or change tires and tubes.
2. Service landing gear wheel bearings, such as cleaning, greasing or replacing.
3. Service landing gear shock struts by adding air, oil or both.
4. Replace defective safety wire and cotter keys.
5. Lubrication not requiring disassembly other than removal of non-structural items such as cover plates, cowling or fairings.
6. Replenish hydraulic fluid in the hydraulic reservoirs.
7. Refinish the exterior or interior of the aircraft (excluding balanced control surfaces) when removal or disassembly of any primary structure or operating system is not required.
8. Replace side windows and safety belts.
9. Replace seats or seat parts with replacement parts approved for the aircraft.
10. Replace bulbs, reflectors and lenses of position and landing lights.
11. Replace cowling not requiring removal of the propeller.
12. Replace, clean or set spark plug clearance.
13. Replace any hose connection, except hydraulic connections, with replacement hoses.
14. Replace pre-fabricated fuel lines.
15. Replace the battery and check fluid level and specific gravity.

Although the above work is allowed by law, each individual should make a self analysis as to whether he has the ability to perform the work.

If the above work is accomplished, an entry must be made in the appropriate log book. The entry should contain:

1. The date the work was accomplished.
2. Description of the work.
3. Number of hours on the aircraft.
4. The certificate number of pilot performing the work.
5. Signature of the individual doing the work.

REQUIRED SERVICE AND INSPECTION PERIODS

Piper Aircraft Corporation provides for the initial and first 50-hour inspection, at no charge to the owner. The **Owner Service Agreement** which the owner receives upon delivery of the aircraft should be kept in the aircraft at all times. This identifies him to authorized Piper dealers and entitles the owner to receive service in accordance with the regular service agreement terms. This agreement also entitles the transient owner full warranty by any Piper dealer in the world.

One hundred hour inspections are required by law if the aircraft is used commercially. Otherwise this inspection is left to the discretion of the owner. This inspection is a complete check of the aircraft and its systems, and should be accomplished by a Piper Authorized Service Center or by a qualified aircraft and power plant mechanic who owns or works for a reputable repair shop. The inspection is listed, in detail, in the inspection report of the appropriate Service Manual.

An **annual inspection** is required once a year to keep the Airworthiness Certificate in effect. It is the same as a 100-hour inspection except that it must be signed by an Inspection Authorized (IA) mechanic or a General Aviation District Office (GADO) representative. This inspection is required whether the aircraft is operated commercially or for pleasure.

A **Progressive Maintenance** program is approved by the FAA and is available to the owner. It involves routine and detailed inspections at 50-hour intervals. The purpose of the program is to allow maximum utilization of the aircraft, to reduce maintenance inspection cost and to maintain a maximum standard of continuous airworthiness. Complete details are available from Piper dealers.

A **spectographic analysis** of the oil is available from several sources. This system, if used intelligently, provides a good check of the internal condition of the engine. For this system to be accurate, oil samples must be sent in at regular intervals, and induction air filters must be cleaned or changed regularly.

TYPE OF LUBRICANT			PREFERRED PRODUCT AND VENDOR
IDENTIFICATION LETTER	LUBRICANT	SPECIFICATION	
A	LUBRICATING OIL, GENERAL PURPOSE, LOW TEMP.	MIL-L-7870	
B	LUBRICATING OIL, AIRCRAFT RECIPROCATING ENGINE (PISTON) GRADE AS SPECIFIED SAE 50 ABOVE 60°F AIR TEMP. SAE 40 30° TO 50°F AIR TEMP. SAE 30 10° TO 30°F AIR TEMP. SAE 20 BELOW 10°F AIR TEMP.	MIL-L-6082	
C	HYDRAULIC FLUID, PETROLEUM BASE.	MIL-H-6606	
D	GREASE, AIRCRAFT AND INSTRUMENT GEAR AND ACTUATOR SCREW GREASE, AIRCRAFT, HIGH TEMP.	MIL-G-23827	TEXACO MARFAK ALL PURPOSE GREASE, MOBIL GREASE 77 (OR MOBILUX EP2), SHELL ALVANIA EP GREASE 2
F	PARKER "O" RING LUBRICANT		FISKE BROS. REFINING CO.
G	AERO LUBRIPLATE		
H	FLUOROCARBON RELEASE AGENT DRY LUBRICANT	* MS-122	
I	GEN. PURPOSE AIRCRAFT GREASE - LUBRICANT	MIL-G-7711	


SPECIAL INSTRUCTIONS	
1.	AIR FILTER - TO CLEAN FILTER, TAP GENTLY TO REMOVE DIRT PARTICLES. DO NOT BLOW OUT WITH COMPRESSED AIR OR USE OIL. REPLACE FILTER IF PUNCTURED OR DAMAGED.
2.	BEARINGS AND BUSHINGS - CLEAN EXTERIOR WITH A DRY TYPE SOLVENT BEFORE LUBRICATING.
3.	WHEEL BEARINGS - DISASSEMBLE AND CLEAN WITH A DRY TYPE SOLVENT. ASCERTAIN THAT GREASE IS PACKED BETWEEN THE BEARING ROLLER AND CONE. DO NOT PACK GREASE IN WHEEL HOUSING.
4.	OIL STRUTS AND BRAKE RESERVOIR - FILL PER INSTRUCTIONS ON UNIT OR CONTAINER, OR REFER TO SERVICE MANUAL, SECTION II.
5.	"O" RING, CONTROL SHAFT BUSHING (WITH 1.125 INCH SHAFT ONLY) - DISASSEMBLE "O" RING, RETAINER PLATES FROM INSTRUMENT PANEL, LUBRICATE "O" RING AND REASSEMBLE.
6.	LUBRICATION POINTS - WIPE ALL LUBRICATION POINTS CLEAN OF OLD GREASE, OIL, DIRT, ETC. BEFORE LUBRICATING.
7.	INTERVALS BETWEEN OIL CHANGES CAN BE INCREASED AS MUCH AS 100% ON ENGINES EQUIPPED WITH FULL FLOW (CARTRIDGE TYPE) OIL FILTERS - PROVIDED THE ELEMENT IS REPLACED EACH 50 HOURS OF OPERATION.

NOTES	
1.	PILOT AND PASSENGER SEATS - LUBRICATE TRACK ROLLERS AND STOP PINS AS REQUIRED. (TYPE OF LUBRICANT: "A")
2.	WHEEL BEARINGS - REQUIRE CLEANING AND REPACKING AFTER EXPOSURE TO AN ABNORMAL QUANTITY OF WATER.
3.	FUEL SELECTOR VALVE - LUBRICATE FUEL SELECTOR VALVE AS REQUIRED. REFER TO PIPER SERVICE LETTER NO. 361.
4.	SEE LYCOMING SERVICE INSTRUCTIONS NO. 1014 FOR USE OF DETERGENT OIL.

CAUTIONS	
1.	DO NOT USE HYDRAULIC FLUID WITH A CASTOR OIL OR ESTER BASE.
2.	DO NOT OVER-LUBRICATE COCKPIT CONTROLS.
3.	DO NOT APPLY LUBRICANT TO RUBBER PARTS.

EXAMPLE	
METHOD OF LUBRICATION	FREQUENCY OF LUBRICATION
TYPE OF LUBRICANT	SPECIAL INSTRUCTIONS

Lubrication Nomenclature



Lubrication Chart

Aircraft Service Registration and Equipment Identification

Owner Copy (to be kept with aircraft)

019626

CUSTOMER DELIVERY DATE

4/22/74

PIPER DISTRIBUTOR

EGGONS GLAD

A/C MODEL	Piper PA-28-151	SER. NO.	28-7415398	REGISTRATION NO.	N42671
-----------	-----------------	----------	------------	------------------	--------

A. OWNER'S NAME Piper Aircraft Corporation		B. DEALER	
ADDRESS P.O. Box 1328		ADDRESS	
CITY Vero Beach		CITY STATE ZIP	
STATE Florida ZIP 32960		C. SIGNATURE	

EQUIPMENT IDENTIFICATION - FACTORY INSTALLED

ENGINE(S)	MODEL	SERIAL NUMBER	PROPELLER	MODEL	SERIAL NUMBERS
1. LEFT (OR SINGLE)	00320-E3D Lycoming	L-37856-27A	3. HUB	74DM6-0-58 Sensenich	K-37552
2. RIGHT (MULTI)			4. BLADE		
			5. HUB		
			6. BLADE		

AVIONICS

MFR.	NOMENCLATURE AND MODEL	SER. NO.	MFR.	NOMENCLATURE AND MODEL	SER. NO.
7. Garrett	RESCU 88	73C-1633	34.		
8. King	ADF KR-85	14132	35.		
9. King	KI-225	14105	36.		
10. King	KMA-20	7130	37.		
11. King	KA-23	2613	38.		
12. King	KI-201C	13227	39.		
13. King	KI-214	3311	40.		
14. King	KX-170B	22001	41.		
15. King	KX-170B	22239	42.		
16. King	KT-78	13048	43.		
17.			44.		
18.			45.		
19.			46.		
20.			47.		
21.			48.		
22.			49.		
23.			50.		
24.			51.		
25.			52.		
26.			53.		
27.			54.		
28.			55.		
29.			56.		
30.			57.		
31.			58.		
32.			59.		
33.			60.		

AUTOMATED FLIGHT SYSTEM

NOMENCLATURE	SER. NO.	NOMENCLATURE	SER. NO.	NOMENCLATURE	SER. NO.
61. Autocontrol III	8184	69.		77.	
62. Console Amp	5796D	70.		78.	
63. Roll Servo	10825A	71.		79.	
64. DG	22336E	72.		80.	
65. AH	26427F	73.		81.	
66. Omni Coupler	P-9300-G	74.		82.	
67.		75.		83.	
68.		76.		84.	



